Original		Replacement	
ON/OFF	On/Off	Power	Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
AV 0	0/AV	HDMI-SAT 0	0
P+	Up		Up
P+	P+	CH PAGE +	CH+ / Page+
	Right		Right
	Vol +	VOL +	Vol +
	Vol -	VOL -	Vol -
	Left		Left

Original		Replacement	
OK	OK	OK	OK
P-	P-	CH PAGE -	CH- / Page-
	Down		Down
i	i	ANGLE INFO	Info / Angle
	Timer	TIMER SLEEP	Sleep / Timer
TXT	TXT	GOTO TEXT	Text / Goto
	Mute	DIMMER MUTE	Mute / Dimmer
MOVIES	Red	NETFLIX SEARCH	Red / Netflix / Search
MOVIES	Movies	RDS AV INPUT	AV / Input / RDS
INTERNET	Green	APP REPEAT	Green / APP / Repeat
INTERNET	Internet	LIST SMART	Smart / List
MENU	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
MENU	Menu	HOME MENU	Menu / Home
GAMES	Blue	Prime Video RANDOM	Blue / Prime Video / Random
GAMES	Games	SIZE ZOOM	Zoom / Size
-	- Color	TUNE-	<< / Tune-
+	Colour +	TUNE+	>> / Tune+

Original		Replacement		Original		Replacement	
	- ☼	PRESET-	I<< / Preset-				
	☼ +	PRESET+	>>I / Preset+				
E-MAIL	E-Mail	MEDIA DISPLAY	Display / Media				
WAKE UP	Wake Up	EQ SUBTITLE	Subtitle / EQ				
MESSAGE	Message	OPT-TOOLS SETUP	Setup / OPT /				
BILL VIEW	Bill View	PC FAV MARKER	Fav / Marker / PC				
PAY ACCEPT	Pay Accept	-/-- GUIDE EPG	Guide / EPG / -/--				
RADIO	Radio	PROGRAM TV/RADIO	TV/Radio /				