Original		Replacement	
AVR Power On		Power	
AVR Power Off		SHIFT +	Shift + Power
Cable/Sat		SHIFT + HDMI - SAT 0	Shift + 0
Disc		SHIFT + DVD 2	Shift + 2
DVR		SHIFT + CD - STB 3	Shift + 3
Radio		SHIFT + TUNER 6	Shift + 6
TV		SHIFT + TV 1	Shift + 1
USB		SHIFT + USB 8	Shift + 8
Game		SHIFT + VIDEO 4	Shift + 4
Media Server		SHIFT + BLUETOOTH 9	Shift + 9
Network		SHIFT + TAPE 5	Shift + 5
AUX		SHIFT + AUX - HDD 7	Shift + 7
Audio Effects		LANG I/II AUDIO	Audio / Lang I/II
Video Modes		FORMAT PICTURE	Picture / Format
Surround Modes		SURROUND	Eject / Surround
1		TV 1	1
2		DVD 2	2

Original		Replacement	
3		CD - STB 3	3
4		VIDEO 4	4
5		TAPE 5	5
6		TUNER 6	6
7		AUX - HDD 7	7
8		USB 8	8
9		BLUETOOTH 9	9
Last		RETURN BACK	Back / Return
0		HDMI - SAT 0	0
Back/Exit		CLEAR EXIT CANCEL	Exit / Cancel / Clear
Up			Up
Menu		HOME MENU	Menu / Home
Left			Left
OK		OK	OK
Right			Right
Down			Down
Red		NETFLIX SEARCH	Red / Netflix / Search

Original	Replacement	Original	Replacement
Green	Green / APP / Repeat	Sleep	Sleep / Timer
Yellow	Yellow / YouTube / Repeat		
Blue	Blue / Prime Video / Random		
Vol +	Vol +		
Mute	Mute / Dimmer		
CH/Page Up	CH+ / Page+		
Vol -	Vol -		
CH/Page Down	CH- / Page-		
I<<	I<< / Preset-		
Pause	Pause / Step / Freeze		
>>I	>>I / Preset+		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		
Stop	Stop / Hold		
AVR	Smart / List		
Info	Info / Angle		

Original	Replacement	Original	Replacement
Disc Power On	Power	Left	Left
Disc Power Off	Shift + Power	OK	OK
Disc	Display / Media	Right	Right
1	1	Down	Down
2	2	Disc Menu	D.Menu / Top
3	3	Red	Red / Netflix / Search
4	4	Green	Green / APP / Repeat
5	5	Yellow	Yellow / YouTube / Repeat
6	6	Blue	Blue / Prime Video / Random
7	7	Vol +	Vol +
8	8	Mute	Mute / Dimmer
9	9	Vol -	Vol -
Last	Back / Return	I<<	I<< / Preset-
0	0	Pause	Pause / Step / Freeze
Back/Exit	Exit / Cancel / Clear	>>I	>>I / Preset+
Up	Up	<<	<< / Tune-
Menu	Menu / Home	Play	Play / Slow

Original		Replacement		Original		Replacement
	>>	TUNE+	>> / Tune+			
	Rec	REC MODE	Rec / Rec Mode			
	Stop	HOLD	Stop / Hold			

Original		Replacement	
ON Device	DVR Power On		Power
DVR	DVR	MEDIA DISPLAY	Display / Media
1	1	TV 1	1
ABC 2	2	DVD 2	2
DEF 3	3	CD - STB 3	3
GHI 4	4	VIDEO 4	4
JKL 5	5	TAPE 5	5
MNO 6	6	TUNER 6	6
PQRS 7	7	AUX - HDD 7	7
TUV 8	8	USB 8	8
WXYZ 9	9	BLUETOOTH 9	9
>9 0	0	HDMI - SAT 0	0
	Up		Up
MENU	Menu	HOME MENU	Menu / Home
	Left		Left
	Right		Right
	Down		Down

Original		Replacement	
+ VOL	Vol +	+ VOL	Vol +
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
CH Page	CH/Page Up	+ CH PAGE	CH+ / Page+
VOL −	Vol -	VOL −	Vol -
CH Page	CH/Page Down	CH PAGE −	CH- / Page-

Original		Replacement	
AVR Power On		Power	
AVR Power Off		Shift	+ Power
Cable/SAT		Shift	+ 0
Disc		Shift	+ 2
DVR		Shift	+ 3
Radio		Shift	+ 6
TV		Shift	+ 1
USB		Shift	+ 8
Game		Shift	+ 4
Media Server		Shift	+ 9
Network		Shift	+ 5
AUX		Shift	+ 7
Audio Effects		Audio / Lang I/II	
Video Modes		Picture / Format	
Surround Modes		Eject / Surround	
1		1	
2		2	

Original		Replacement	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	
Last		Back / Return	
0		0	
Back/Exit		Exit / Cancel / Clear	
Up		Up	
Menu		Menu / Home	
Left		Left	
OK		OK	
Right		Right	
Down		Down	
Red		Red / Netflix / Search	

Original		Replacement	
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Vol +		Vol +
	Mute		Mute / Dimmer
	CH/Page Up		CH+ / Page+
	Vol -		Vol -
	CH/Page Down		CH- / Page-
	I<<		I<< / Preset-
	Pause		Pause / Step / Freeze
	>>I		>>I / Preset+
	<<		<< / Tune-
	Play		Play / Slow
	>>		>> / Tune+
	Rec		Rec / Rec Mode
	Stop		Stop / Hold
	AVR		Smart / List

Original		Replacement	
	Info		Info / Angle
	Sleep		Sleep / Timer