Original	Replacement	Original	Replacement
Power	Power	Down/ CH-	Down
Mute	Mute	Right	Right
1	1	Left	Left
2	2	OK	Ok
3	3	Vol +	Vol +
4	4	Vol -	Vol -
5	5	Menu	Menu
6	6	Exit	Exit
7	7	Red	Red
8	8	Green	Green
9	9	Yellow	Yellow
0	0	Blue	Blue
PgUp	Ch +	EPG	Guide
PgDn	Ch -	Audio	Dual
FAV+	>>|	SUB	Subt
FAV-	|<<	Zoom	Eject
Up/ CH+	Up	FAV	Pre Ch

Original		Replacement		Original	Replacement
	List		List		
	Pause		Pause		
	TXT		Text		
	Info		Info		
	Tv/Radio		TV/R		
	Recall		Back		