Original	Replacement	Original	Replacement
Power Audio	Power	A-B RPT	SHIFT + 2 (Shift + 2)
Power TV	SHIFT + Power (Shift + Power)	Sleep	PROG SLEEP (Sleep)
1	1	Top Menu	SHIFT + TOP MENU MENU (Shift + Menu)
2	2	Dimmer	HOME SMART (Smart)
3	3	Menu PL	TOP MENU MENU (Menu)
4	4	FL Display	SHIFT + DISPLAY INFO (Shift + Info)
5	5	Setting	SETTINGS OPT (Options)
6	6	On Screen	ECO 3D (3D)
7	7	PTY Search	SHIFT + ▲ (Shift + Up)
8	8	Display	DISPLAY INFO (Info)
9	9	Set Up	SHIFT + SETTINGS OPT (Shift + Options)
0	0	TA/News/Info	SHIFT + ▼ (Shift + Down)
10	GUIDE (Guide)	Up	▲ (Up)
≥10	FAV PRE-CH (Pre Ch)	Down	▼ (Down)
Tv/Video	SEARCH TV/R (TV/R)	Right	▶ (Right)
Title/Group	E-MANUAL D.MENU (D. Menu)	Left	◀ (Left)
Repeat	REPEAT TEXT (Text)	ENTER	OK (Ok)

Original		Replacement	
PTY ⊕	+ PTY	SHIFT + ▶	Shift + Right
⊖ PTY	- PTY	SHIFT + ◀	Shift + Left
DVD ▶	Play DVD	PLAY MODE ▶	Play
USB MEMORY ▶	Play USB	DISC NAV LIST	List
FM/AM	FM/AM	SHIFT + SEARCH TV/R	Shift + TV/R
MEMORY ■	Stop / Memory	■	Stop
TV SOUND	TV Sound	SHIFT + SOUND DUAL	Shift + Dual
FM MODE ❚❚	Pause/FM Mode	❚❚	Pause
⊖ TUNI ⏮	I<< / Tuning-	⏮	I<<
JNING ⊕ ⏭	>>I / Tuning+	⏭	>>I
SURROUND	Surround	APP MEDIA	Media
⊖ SLOW ◀◀	<< / Slow-	◀◀	<<
SLOW ⊕ ▶▶	>> / Slow+	▶▶	>>
↩	Back	RETURN BACK	Back
RETURN	Return	SHIFT + RETURN BACK	Shift + Back
SUBTITLE	Subtitle	AD SUBT	Subt
SPK-LEVEL	SPK-Level	A	Red

Original		Replacement	
AUDIO	Audio	SOUND DUAL	Dual
ANGLE	Angle	PICTURE FORMAT	Format
ZOOM	Zoom	ZOOM ⏏	Eject
SCAN MODE VFP	VFP/Scan Mode	B	Green
PLAY MODE	Play Mode	SHIFT + PLAY MODE ▶	Shift + Play
TV CH +	Level+	+ CH	Ch +
− LEVEL	Level-	CH −	Ch -
− LEVEL	Tv CH+	SHIFT + CH −	Shift + Ch -
TV CH +	Tv CH-	SHIFT + + CH	Shift + Ch +
CANCEL	Cancel	CLEAR EXIT	Exit
+	Audio Vol+	+ VOL	Vol +
− TV VOL AUDIO VOL	Audio Vol-	VOL −	Vol -
− TV VOL AUDIO VOL	TV Vol+	SHIFT + VOL −	Shift + Vol -
+	Tv Vol-	SHIFT + + VOL	Shift + Vol +
MUTING	Muting	MUTE	Mute