| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| 1 | 1 | 1 | 1 |
| 2 ABC | 2 | 2 | 2 |
| 3 DEF | 3 | 3 | 3 |
| 4 GHI | 4 | 4 | 4 |
| 5 JKL | 5 | 5 | 5 |
| 6 MNO | 6 | 6 | 6 |
| 7 PQRS | 7 | 7 | 7 |
| 8 TUV | 8 | 8 | 8 |
| 9 WXYZ | 9 | 9 | 9 |
| LANG. | Lang | AUDIO | Audio / Lang I/II |
| 0 | 0 | 0 | 0 |
| TXT | TXT | TEXT | Text / Goto |
| V- | V- | VOL - | Vol - |
| V+ | V+ | VOL + | Vol + |
| | Mute | MUTE | Mute / Dimmer |
| P | P+ | CH PAGE + | CH+ / Page+ |

| Original | | Replacement | |
|---|---|---|---|
| P | P- | CH PAGE - | CH- / Page- |
| | Source | AV INPUT | AV / Input / RDS |
| | Home | MENU | Menu / Home |
| | [G] | GUIDE EPG | Guide / EPG / -/-- |
| i | i | INFO | Info / Angle |
| | Up | | Up |
| | Left | | Left |
| OK | OK | OK | OK |
| | Right | | Right |
| | Down | | Down |
| BACK | Back | BACK | Back / Return |
| EXIT | Exit | EXIT | Exit / Cancel / Clear |
| NETFLIX | Netflix | SHIFT + NETFLIX | Shift + Red / Netflix / |
| YouTube | YouTube | SHIFT + YouTube | Shift + Yellow / YouTube / |
| prime video | prime video | SHIFT + Prime Video | Shift + Blue / Prime |
| Rakuten TV | Rakuten Tv | PROGRAM TV/RADIO | TV/Radio / |
| twitch | twitch | SIZE ZOOM | Zoom / Size |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| ☆ | ☼1 | OPT-TOOLS SETUP | Setup / OPT / | | |
| | Red | NETFLIX SEARCH | Red / Netflix / Search | | |
| | Green | APP REPEAT | Green / APP / Repeat | | |
| | Yellow | YouTube REPEAT A-B | Yellow / YouTube / Repeat | | |
| | Blue | Prime Video RANDOM | Blue / Prime Video / Random | | |
| ◀◀ | << | TUNE- ◀◀ | << / Tune- | | |
| ■ | Stop | HOLD ■ | Stop / Hold | | |
| ▶▶ | >> | TUNE+ ▶▶ | >> / Tune+ | | |
| ● | Rec | REC MODE ● | Rec / Rec Mode | | |
| ▶ | Play | SLOW ▶ | Play / Slow | | |
| ❚❚ | Pause | STEP-FREEZE ❚❚ | Pause / Step / Freeze | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |