Mandis shop

LG AKB73655901

Original		Replacement		Original	Replacement
	Power		Power		
BACK	Back	RETURN BACK	Back		
HOME	Home	HOME SMART	Smart		
	Up		Up		
	Down		Down		
	Left		Left		
	Right		Right		
	OK	OK	Ok		
INFO/ MENU	Info/Menu	TOP MENU MENU	Menu		
	Play/Pause	PLAY MODE	Play		
	Stop		Stop		
	I<<</<<		<<		
	>>I/>>	CH –	Ch -		
	Red	A	Red		
	Green	B	Green		
	Yellow	C	Yellow		
	Blue	D	Blue		

https://telecommandes-mandis.be/en/LG/1039038-65408-replacement-remote-control-for-LG-AKB73655901.html