# Mandis shop

LG AKB37026816

| Original | | Replacement | |
|---|---|---|---|
| POWER | Power | | Power |
| OPEN/CLOSE | Open/Close | FAV 2. P/C | P/C / FAV |
| FUNCTION | Function | MEDIA | MEDIA |
| SLEEP | Sleep | EPG 1. -/-- | -/-- / EPG |
| TITLE | Title | WIDE | WIDE |
| DISPLAY | Display | INFO | INFO |
| MENU | Menu | MENU | MENU |
| SETUP | Setup | VOD | VOD |
| ^ | Preset Up | ▲ | UP |
| v | Preset Down | ▼ | DOWN |
| < | Left/Tun- | ◄ | LEFT |
| > | Right/Tun+ | ► | RIGHT |
| ENTER | Enter | OK | OK |
| RETURN | Return | BACK | BACK |
| REC | Rec | ● | Rec |
| STOP | Stop | ■ | Stop |
| MO./ST. PLAY | Play/Mo/St. | ▶ | Play |

| Original | | Replacement | |
|---|---|---|---|
| PAUSE/STEP | Pause//Step | II | Pause |
| SKIP | I<< Skip | ⏮ | First |
| ◄◄ | <<Scan | ◄◄ | Rewind |
| ►► | >>Scan | ►► | Fast Forward |
| SKIP | >>I Skip | ⏭ | Last |
| TV→HT SPK | Audio/Tv→HT SPK | 🔈? | Audio |
| MUTE | Mute | 🔇 | MUTE |
| + VOL | Vol + | + VOL | VOL + |
| VOL − | Vol - | VOL − | VOL - |
| LG EQ | ♫LG-EQ | OPT+ | OPT+ |
| 1 | 1 | 1..? | 1 |
| 2 | 2 | 2ABC | 2 |
| 3 | 3 | 3DEF | 3 |
| 4 | 4 | 4GHI | 4 |
| 5 | 5 | 5JKL | 5 |
| 6 | 6 | 6MNO | 6 |
| 7 | 7 | 7PQRS | 7 |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| 8 | 8 | 8 | 8 | | |
| 9 | 9 | 9 | 9 | | |
| 0 | 0 | 0 | 0 | | |
| REPEAT RANDOM | Random/ Repeat | TEXT | TEXT | | |
| SUBTITLE | [ . . . ] / Subtitl | | Subt. | | |
| POWER | Power Tv | SHIFT + | Shift + Power | | |
| + PR/CH | PR/ CH+Tv | + CH | CH + | | |
| PR/CH − | PR/ CH- Tv | CH − | CH - | | |
| VOL − | Vol - Tv | SHIFT + | Shift + LEFT | | |
| + VOL | Vol +Tv | SHIFT + | Shift + RIGHT | | |
| PROG.MEMO | Prog. Memo | V-FOR | V- FOR | | |
| CLEAR | Clear | EXIT | EXIT | | |
| RDS RESOLUTION | RDS | TV/R | TV/ R | | |
| RESOLUTION PTY | PTY/ Resolution | SRC | SRC | | |
| EQ | EQ | SHIFT + | Shift + Audio | | |
| INPUT | Input Tv | SHIFT + SRC | Shift + SRC | | |
| | | | | | |