Original		Replacement		Original		Replacement	
	Power		Power	FLASHBK	Flashbk	GUIDE EPG	Guide / EPG / -/--
TV/PC	TV/PC	PROGRAM TV/RADIO	TV/Radio /	VOL	Vol +	VOL	Vol +
CAPTION	Caption	EQ SUBTITLE	Subtitle / EQ	FAV	FAV	PC FAV MARKER	Fav / Marker / PC
AV MODE	AV Mode	SIZE ZOOM	Zoom / Size	CH PAGE	CH/Page+	CH PAGE	CH+ / Page+
RATIO	Ratio	MEDIA DISPLAY	Display / Media	VOL	Vol -	VOL	Vol -
INPUT	Input	RDS AV INPUT	AV / Input / RDS	AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
1	1	TV 1	1	CH PAGE	CH/Page-	CH PAGE	CH- / Page-
2	2	DVD 2	2	MUTE	Mute	DIMMER MUTE	Mute / Dimmer
3	3	CD - STB 3	3	PICTURE	Picture	FORMAT PICTURE	Picture / Format
4	4	VIDEO 4	4	INFO	Info	ANGLE INFO	Info / Angle
5	5	TAPE 5	5	SOUND	Sound	TITLE SOUND	Sound / Title
6	6	TUNER 6	6	SETTINGS	Settings	OPT-TOOLS SETUP	Setup / OPT /
7	7	AUX - HDD 7	7		Up		Up
8	8	USB 8	8	Q.MENU	Q.Menu	TOP MENU D.MENU	D.Menu / Top
9	9	BLUETOOTH 9	9		Left		Left
LIST	List	LIST SMART	Smart / List	OK	OK	OK	OK
0	0	HDMI - SAT 0	0		Right		Right

Original		Replacement		Original	Replacement
BACK	Back	RETURN BACK	Back / Return		
▼	Down	▼	Down		
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer		
■	Stop	HOLD ■	Stop / Hold		
◀◀	<<	TUNE- ◀◀	<< / Tune-		
▶	Play	SLOW ▶	Play / Slow		
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze		
▶▶	>>	TUNE+ ▶▶	>> / Tune+		
•	Red/ 1	NETFLIX SEARCH	Red / Netflix / Search		
••	Green/ 2	APP REPEAT	Green / APP / Repeat		
∴	Yellow/ 3/ ☼-	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
⁘	Blue/ 4/ ☼+	Prime Video RANDOM	Blue / Prime Video / Random		