Mandis shop

RC- 82PM

Original		Replacement		Original	Replacement
PHONO	Phono	USB 8	8		
CD	CD	CD - STB 3	3		
TUNER	Tuner	TUNER 6	6		
1—A	AUX 1	VIDEO 4	4		
JX—2	AUX 2	AUX - HDD 7	7		
TAPE 1	Tape 1	TV 1	1		
DCC/ TAPE 2	DCC/ Tape 2	DVD 2	2		
TAPE 3	Tape 3	TAPE 5	5		
PROCESSOR	Processor	LIST SMART	Smart / List		
VOLUME	Volume+	+ VOL	Vol +		
MUTING	Muting	DIMMER MUTE	Mute / Dimmer		
VOLUME	Volume-	VOL –	Vol -		

https://telecommands.be/en/Marantz/10556-1964-replacement-remote-control-for-Marantz-RC82PM-KX3700.html