Original		Replacement	
Power		Power	
Mute		Mute / Dimmer	DIMMER MUTE
Text / Play/Paus		Play / Slow	SLOW
Text / Play/Paus		Pause / Step / Freeze	STEP-FREEZE
Text / Play/Paus		Text / Goto	GOTO TEXT
Still / Stop		Stop / Hold	HOLD
Radio		TV/Radio /	PROGRAM TV/RADIO
Aspect / Size		Zoom / Size	SIZE ZOOM
Red / <<		<< / Tune-	TUNE-
Red / <<		Red / Netflix / Search	NETFLIX SEARCH
Green / >>		Green / APP / Repeat	APP REPEAT
Green / >>		>> / Tune+	TUNE+
Yellow / I<<		Yellow / YouTube / Repeat	YouTube REPEAT A-B
Yellow / I<<		I<< / Preset-	PRESET-
Blue / >>I		>>I / Preset+	PRESET+
Blue / >>I		Blue / Prime Video / Random	Prime Video RANDOM
Source		AV / Input / RDS	RDS AV INPUT

Original		Replacement	
Menu		Menu / Home	HOME MENU
Up		Up	
Left		Left	
Enter		OK	
Right		Right	
Down		Down	
Info		Info / Angle	ANGLE INFO
Exit		Exit / Cancel / Clear	CLEAR EXIT CANCEL
Vol +		Vol +	
Index		Display / Media	MEDIA DISPLAY
CH +		CH+ / Page+	CH PAGE
Vol -		Vol -	
List		Smart / List	LIST SMART
CH -		CH- / Page-	CH PAGE
1		1	TV 1
2		2	DVD 2
3		3	CD-STB 3

Original		Replacement		Original	Replacement
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
AUDIO I/II	Audio / I/II	LANG I/II AUDIO	Audio / Lang I/II		
0	0	HDMI - SAT 0	0		
DVB	DVB	TOP MENU D.MENU	D. Menu / Top		
♥	FAV	PC FAV MARKER	Fav / Marker / PC		
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer		
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--		
⟲	Prev. CH.	RETURN BACK	Back / Return		
EX	Cancel	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear		
SUBTITLE EQ	Subtitle	EQ SUBTITLE	Subtitle / EQ		
USB	USB	SHIFT + USB 8	Shift + 8		
●	Rec	REC MODE	Rec / Rec Mode		