Original		Replacement	
ON	Power On		Power
STNBY	Power/Standby	SHIFT +	Shift + Power
SLEEP	Sleep	PROG SLEEP	Sleep
DISPLAY DVD SET	Display/DVD	APP MEDIA	Media
OSD MENU	OSD Menu	TOP MENU MENU	Menu
CH	CH+	+ CH	Ch +
CH	CH-	CH –	Ch -
VOL	Vol+	+ VOL	Vol +
VOL	Vol-	VOL –	Vol -
	Up		Up
	Left		Left
ENTER	Enter	OK	Ok
	Right		Right
	Down		Down
EXIT RETURN	Exit/Return	CLEAR EXIT	Exit
TEST TV/VCR	Test/Tv/VCR	SEARCH TV/R	TV/R
MUTING	Muting	MUTE	Mute

Original		Replacement	
	I<<		I<<
	Play	PLAY MODE	Play
	>>I		>>I
	<<		<<
	Stop		Stop
	>>		>>
REC	Rec	REC MODE	Rec
	Pause		Pause
OPEN/CLOSE	Eject	ZOOM	Eject
DVD	DVD	SETTINGS OPT	Options
CD	CD	REPEAT TEXT	Text
T1	T1	PICTURE FORMAT	Format
T2	T2	SOUND DUAL	Dual
TUN	Tun	TIMER AV	AV
PH	PH	ECO 3D	3D
V1	V1	A	Red
V2	V2	B	Green

Original		Replacement		Original	Replacement
V3	V3	C	Yellow		
V_	V4	D	Blue		
STEREO 1	1/Stereo	1	1		
DIRECT 2	2/Direct	2	2		
DSP ► 3	3/DSP>	3	3		
SURROUND 4	4/Surround	4	4		
THX 5	5/THX	5	5		
DSP ◄ 6	6/DSP<	6	6		
Re-EQ 7	7/Re-EQ	7	7		
CH SEL 8	8/CH Sel	8	8		
LEVEL+ 9	9/Level+	9	9		
LATE NIGHT +10	+10/Late Night	GUIDE	Guide		
DIMMER 0	0/Dimmer	0	0		
LEVEL- ENT	ENT/Level-	PRE-CH	Pre Ch		

Original		Replacement	
ON	Power		Power
DISPLAY DVD SET	Display DVD	APP MEDIA	Media
OSD MENU	OSD Menu	TOP MENU MENU	Menu
	Up		Up
	Left		Left
ENTER	Enter	OK	Ok
	Right		Right
	Down		Down
EXIT RETURN	Exit/Return	CLEAR EXIT	Exit
	I<<		I<<
	Play	PLAY MODE	Play
	>>I		>>I
	<<		<<
	Stop		Stop
	>>		>>
	Pause		Pause
OPEN/CLOSE	Eject	ZOOM	Eject

Original		Replacement	
STEREO 1	1	1	1
DIRECT 2	2	2	2
DSP 3	3	3	3
SURROUND 4	4	4	4
THX 5	5	5	5
DSP 6	6	6	6
Re-EQ 7	7	7	7
CH SEL 8	8	8	8
LEVEL+ 9	9	9	9
DIMMER 0	0	0	0
LATE NIGHT +10	+10	-/-- GUIDE	Guide
LEVEL- ENT	Ent	FAV PRE-CH	Pre Ch

Original		Replacement	
	Play	PLAY MODE ▶	Play
	Stop	■	Stop
	Pause	❚❚	Pause
	I<<	⏮	I<<
	<<	«	<<
	>>	»	>>
TRACK	Track	HOME SMART	Smart
DISC	Disc	APP MEDIA	Media
	>>I	⏭	>>I
OPEN/CLOSE	Eject	ZOOM ⏏	Eject
STEREO 1	1	1	1
DIRECT 2	2	2	2
DSP 3	3	3	3
SURROUND 4	4	4	4
THX 5	5	5	5
DSP 6	6	6	6
Re-EQ 7	7	7	7

Original		Replacement	
CH SEL 8	8	8	8
LEVEL + 9	9	9	9
LATE NIGHT +10	+10	-/-- GUIDE	Guide
DIMMER 0	0	0	0

Original		Replacement	
ON	Power		Power
	I<<		I<<
	Play	PLAY MODE	Play
	>>I		>>I
	<<		<<
	Stop		Stop
	>>		>>
REC	Rec	REC MODE	Rec
	Pause		Pause
OPEN/CLOSE	Eject	ZOOM	Eject
STEREO 1	1	1	1
DIRECT 2	2	2	2
DSP 3	3	3	3
SURROUND 4	4	4	4
THX 5	5	5	5
DSP 6	6	6	6
Re-EQ 7	7	7	7

Original		Replacement	
CH SEL 8	8	8	8
LEVEL + 9	9	9	9
LATE NIGHT +10	+10	GUIDE	Guide
LEVEL - ENT	Ent	FAV PRE-CH	Pre Ch