Mandis shop

Panasonic N2QAEC000003

Original		Replacement	
OSD	OSD	MEDIA DISPLAY	Display / Media
DATE/ TIME	Date/Time	TIMER SLEEP	Sleep / Timer
PHOTO SHOT	Photo Shot	PC FAV MARKER	Fav / Marker / PC
START/ STOP	Start/Stop		Power
COUNTER	Counter	-/-- GUIDE EPG	Guide / EPG / -/--
RESET	Reset	CLEAR EXIT CANCEL	Exit / Cancel / Clear
TITLE	Title	TITLE SOUND	Sound / Title
ZOOM T	Zoom T	CH PAGE	CH+ / Page+
ZOOM T	Vol+	VOL	Vol+
MULTI/ P-IN-P	Multi/P-IN-P	FORMAT PICTURE	Picture / Format
REC	Rec	REC MODE	Rec / Rec Mode
A.DUB	A.DUB	TOP MENU D.MENU	D.Menu / Top
REW	<<	TUNE-	<< / Tune-
PLAY	Play	SLOW	Play / Slow
FF	>>	TUNE+	>> / Tune+
W	Zoom W	CH PAGE	CH- / Page-
W	Vol-	VOL	Vol-

Original		Replacement	
STILL ADV	<I Still ADV	SHIFT +	Shift + Left
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
STILL ADV	Still ADV I>	SHIFT +	Shift + Right
INDEX	I<< Index	PRESET-	I<< / Preset-
STOP	Stop	HOLD	Stop / Hold
INDEX	Index >>I	PRESET+	>>I / Preset+
SELECT	Select	OK	OK
VAR. SEARCH	Var. Search	NETFLIX SEARCH	Red / Netflix / Search
	Up		Up
P.B. ZOOM	P.B. Zoom	SIZE ZOOM	Zoom / Size
STORE	Store	ANGLE INFO	Info / Angle
	Left		Left
MENU	Menu	HOME MENU	Menu / Home
	Right/Set		Right
OFF/ON	On/Off	LIST SMART	Smart / List
	Down/Item		Down

https://telecommandes-mandis.be/en/Panasonic/1058599-9396-replacement-remote-control-for-Panasonic-N2QAEC000003.html