Mandis shop

Panasonic RC45194T

Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Input		AV / Input / RDS
	0		0
	Info		Info / Angle
	Vol +		Vol +
	Mute		Mute / Dimmer
	P+		CH+ / Page+
	Vol -		Vol -

Original		Replacement	
	Voice		Smart / List
	P-		CH- / Page-
	TV		Display / Media
	Guide		Guide / EPG / -/--
	☼		Menu / Home
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	←		Back / Return
	Down		Down
	Exit		Exit / Cancel / Clear
	Netflix		Shift + Red / Netflix /
	YouTube		Shift + Yellow / YouTube /
	prime video		Shift + Blue / Prime
	Disney+		Fav / Marker / PC
	TikTok		Shift + Green / APP / Repeat

Original		Replacement		Original		Replacement	
FREE	Free	FORMAT PICTURE	Picture / Format				
	Red	NETFLIX SEARCH	Red / Netflix / Search				
	Green	APP REPEAT	Green / APP / Repeat				
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
	Blue	Prime Video RANDOM	Blue / Prime Video / Random				
<<	<<	TUNE- <<	<< / Tune-				
■	Stop	HOLD ■	Stop / Hold				
>>	>>	TUNE+ >>	>> / Tune+				
●	Rec	REC MODE ●	Rec / Rec Mode				
II▶	Play	SLOW ▶	Play / Slow				
II▶	Pause	STEP-FREEZE II	Pause / Step / Freeze				
TEXT	Text	GOTO TEXT	Text / Goto				