Original		Replacement	
	Power CD		Power
CD	CD	C	Yellow
PLAY	Play	PLAY MODE	Play
AUX	AUX	A	Red
VCR	VCR	HOME SMART	Smart
TV	TV	APP MEDIA	Media
TUNER	Tuner	B	Green
TAPE	Tape	D	Blue
DISPLAY	Display	DISPLAY INFO	Info
MUTE	Mute	MUTE	Mute
DBB	DBB	-/-- GUIDE	Guide
DSC	DSC	FAV PRE-CH	Pre Ch
SLEEP	Sleep	PROG SLEEP	Sleep
SHUFFLE	Shuffle	SETTINGS OPT	Options
VOLUME +	Volume+	+ VOL	Vol +
VOLUME –	Volume-	VOL –	Vol -
BRIGHTNESS	Brightness	AD SUBT	Subt

Original		Replacement	
STOP	Stop CD		Stop
NEXT	Next >I CD		>>I
PREV.	I< Prev. CD		I<<
PAUSE	Pause CD		Pause
	>> CD		>>
	<< CD		<<
TV VOL +	Tv Vol+		Right
TV VOL –	Tv Vol-		Left
	Power AUX	SHIFT +	Shift + Power
	Power TV	SEARCH TV/R	TV/R

Original		Replacement		Original	Replacement
VCR	VCR	HOME SMART	Smart		
TV	TV	APP MEDIA	Media		
AUX	AUX	A	Red		
TUNER	Tuner	B	Green		
CD	CD	C	Yellow		
TAPE	Tape	D	Blue		
	Power VCR		Power		
MUTE	Mute	MUTE	Mute		
VOLUME +	Volume +	+ VOL	Vol +		
VOLUME –	Volume -	VOL –	Vol -		
PLAY	Play VCR	PLAY MODE	Play		
STOP	Stop VCR		Stop		
PAUSE	Pause VCR		Pause		
PREV.	I< Prev. VCR		I<<		
NEXT	Next >I VCR		>>I		
	<< VCR		<<		
	>> VCR		>>		

Original		Replacement		Original	Replacement
TUNER	Tuner	B	Green		
CD	CD	C	Yellow		
VCR	VCR	HOME SMART	Smart		
TV	TV	APP MEDIA	Media		
AUX	Aux	A	Red		
TAPE	Tape	D	Blue		
	Power Tuner		Power		
VOLUME +	Volume +	+ VOL	Vol +		
VOLUME –	Volume -	VOL –	Vol -		
MUTE	Mute	MUTE	Mute		
NEXT	Next >I Tuner	>>I	>>I		
PREV.	I< Prev. Tuner	I<<	I<<		
	<< Tuner	<<	<<		
	>> Tuner	>>	>>		

Original		Replacement		Original		Replacement	
TAPE	Tape	D	Blue	>>	>> Tape	>>	>>
	Power Tape		Power				
CD	CD	C	Yellow				
TUNER	Tuner	B	Green				
AUX	AUX	A	Red				
VCR	VCR	HOME SMART	Smart				
TV	TV	APP MEDIA	Media				
SIDE	Side Tape	SOUND DUAL	Dual				
MUTE	Mute	MUTE	Mute				
VOLUME +	Volume +	+ VOL	Vol +				
VOLUME –	Volume -	VOL –	Vol -				
PLAY	Play Tape	PLAY MODE	Play				
STOP	Stop Tape		Stop				
NEXT	Next >I Tape	>>I	>>I				
<<	<< Tape	<<	<<				
PREV.	I< Prev. Tape	I<<	I<<				
PAUSE	Pause Tape		Pause				