Original		Replacement	
CD	CD	SHIFT + CD-STB 3	Shift + 3
TAPE	TAPE	SHIFT + TAPE 5	Shift + 5
VCR	VCR	SHIFT + VIDEO 4	Shift + 4
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
TXT	TXT	GOTO TEXT	Text / Goto
DCC	DCC	SHIFT + DVD 2	Shift + 2
DSR	DSR	SHIFT + AUX-HDD 7	Shift + 7
DIG. REC	DIG. REC	SHIFT + USB 8	Shift + 8
TV	TV	SHIFT + TV 1	Shift + 1
A SPEAKERS	Speakers A	LIST SMART	Smart / List
SPEAKERS B	Speakers B	MEDIA DISPLAY	Display / Media
VOLUME AUDIO	Volume Audio +	+ VOL	Vol +
VOLUME AUDIO	Volume Audio -	VOL −	Vol -
VOLUME TV	Volume TV -	◀	Left
VOLUME TV +	Volume TV +	▶	Right
AUDIO PROC −	Audio Processor	▼	Down
PROCESSOR +	Audio Processor	▲	Up

Original		Replacement	
TV	TV -/--	-/-- GUIDE EPG	Guide / EPG / -/--
1	TV 1	TV 1	1
2	TV 2	DVD 2	2
3	TV 3	CD-STB 3	3
4	TV 4	VIDEO 4	4
5	TV 5	TAPE 5	5
6	TV 6	TUNER 6	6
7	TV 7	AUX-HDD 7	7
8	TV 8	USB 8	8
9	TV 9	BLUETOOTH 9	9
0	TV 0	HDMI-SAT 0	0
MUTE	TV Mute	DIMMER MUTE	Mute / Dimmer
PRESET TRACK	TV Preset +	PRESET+ ⏭	>>I / Preset+
PRESET TRACK	TV Preset -	PRESET- ⏮	I << / Preset-
STANDBY	TV Standby	⏻	Power
HOLD STOP	TV-TXT Hold	HOLD ■	Stop / Hold
MEMO OUT PLAY	TV-TXT Memo Out	REC MODE ●	Rec / Rec Mode

Original	Replacement	Original	Replacement
TV-TXT Reveal	Play / Slow	DCC >>	Shift + >> /
TV-TXT Cancel	Exit / Cancel / Clear	DCC Mode	Shift + OK
TV-TXT Time	Sleep / Timer	DCC	Shift + Eject / Surround
TXT Enlarge	Zoom / Size		
TV Mode	OK		
TXT Preset +	CH+ / Page+		
TXT Preset -	CH- / Page-		
DCC Standby	Shift + Power		
DCC Mute	Shift + Mute / Dimmer		
DCC Disc +	Shift + CH+ /		
DCC Disc -	Shift + CH- /		
DCC Track +	Shift + >>I / Preset+		
DCC Track -	Shift + I<< / Preset-		
DCC Stop	Shift + Stop /		
DCC Play	Shift + Play /		
DCC <<	Shift + << /		
DCC Pause	Shift + Pause / Step / Freeze		

Original	Replacement
VCR	SHIFT + VIDEO 4 Shift + 4
TUNER	SHIFT + TUNER 6 Shift + 6
TAPE	SHIFT + TAPE 5 Shift + 5
CD	SHIFT + CD-STB 3 Shift + 3
TXT	GOTO TEXT Text / Goto
TV	SHIFT + TV 1 Shift + 1
DSR	SHIFT + AUX-HDD 7 Shift + 7
DCC	SHIFT + DVD 2 Shift + 2
DIG. REC	SHIFT + USB 8 Shift + 8
Speakers A	LIST SMART Smart / List
Speakers B	MEDIA DISPLAY Display / Media
Volume Audio +	+ VOL Vol +
Volume Audio -	VOL − Vol -
Audio Processor	▲ Up
Audio Processor	▼ Down
Volume TV +	▶ Right
Volume TV -	◀ Left

Original	Replacement
STANDBY CD Standby	⏻ Power
1 CD 1	TV 1 1
2 CD 2	DVD 2 2
3 CD 3	CD-STB 3 3
4 CD 4	VIDEO 4 4
5 CD 5	TAPE 5 5
6 CD 6	TUNER 6 6
7 CD 7	AUX-HDD 7 7
8 CD 8	USB 8 8
9 CD 9	BLUETOOTH 9 9
0 CD 0	HDMI-SAT 0 0
MUTE Mute	DIMMER MUTE Mute / Dimmer
DECK A DISC CD Disc +	+ CH PAGE CH+ / Page+
DISC DECK B CD Disc -	CH PAGE − CH- / Page-
PRESET TRACK CD Track +	PRESET+ ⏭ >>I / Preset+
PRESET TRACK CD Track -	PRESET- ⏮ I<< / Preset-
HOLD STOP CD Stop	HOLD ■ Stop / Hold

Original	Replacement	Original	Replacement
CD Play	Play / Slow		
CD <<	<< / Tune-		
CD Pause	Pause / Step / Freeze		
CD >>	>> / Tune+		
CD Mode	OK		
CD Open/Close	Eject / Surround		
DSR Standby	Shift + Power		
DSR Disc +	Shift + CH+ /		
DSR Disc -	Shift + CH- /		
DSR Preset/Track	Shift + >>I / Preset+		
DSR Preset/Track	Shift + I << / Preset-		
DSR Mode	Shift + OK		

Original	Replacement	Original	Replacement
TUNER	SHIFT + TUNER 6 Shift + 6	TUNER 1	TV 1 1
TAPE	SHIFT + TAPE 5 Shift + 5	TUNER 2	DVD 2 2
VCR	SHIFT + VIDEO 4 Shift + 4	TUNER 3	CD - STB 3 3
CD	SHIFT + CD - STB 3 Shift + 3	TUNER 4	VIDEO 4 4
TV	SHIFT + TV 1 Shift + 1	TUNER 5	TAPE 5 5
DCC	SHIFT + DVD 2 Shift + 2	TUNER 6	TUNER 6 6
DSR	SHIFT + AUX - HDD 7 Shift + 7	TUNER 7	AUX - HDD 7 7
DIG. REC	SHIFT + USB 8 Shift + 8	TUNER 8	USB 8 8
TXT	GOTO TEXT Text / Goto	TUNER 9	BLUETOOTH 9 9
Speakers A	LIST SMART Smart / List	TUNER 0	HDMI - SAT 0 0
Speakers B	MEDIA DISPLAY Display / Media	TUNER Standby	Power
Volume Audio +	+ VOL Vol +	Mute	DIMMER MUTE Mute / Dimmer
Volume Audio -	VOL − Vol -	TUNER Preset +	PRESET+ >>I / Preset+
Volume TV -	Left	TUNER Preset -	PRESET- I << / Preset-
Volume TV +	Right	TUNER <<	TUNE- << / Tune-
Audio Processor	Down	TUNER >>	TUNE+ >> / Tune+
Audio Processor	Up	TUNER Mode	OK OK

Original	Replacement	Original	Replacement
TAPE Standby	SHIFT + Shift + Power		
TAPE Preset +	SHIFT + PRESET+ Shift + >>I / Preset+		
TAPE Deck A	SHIFT + LIST SMART Shift + Smart / List		
TAPE Preset -	SHIFT + PRESET- Shift + I<< / Preset-		
TAPE Deck B	SHIFT + MEDIA DISPLAY Shift + Display / Media		
TAPE Stop	SHIFT + HOLD Shift + Stop /		
TAPE Play	SHIFT + SLOW Shift + Play /		
TAPE <<	SHIFT + TUNE- Shift + << /		
TAPE >>	SHIFT + TUNE+ Shift + >> /		
TAPE Mode	SHIFT + OK Shift + OK		
TAPE Record	SHIFT + REC MODE Shift + Rec / Rec Mode		
TAPE Pause	SHIFT + STEP-FREEZE Shift + Pause / Step /		
TAPE	SHIFT + SURROUND Shift + Eject / Surround		

Original		Replacement	
TAPE	TAPE	SHIFT + TAPE 5	Shift + 5
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
TXT	TXT	GOTO TEXT	Text / Goto
VCR	VCR	SHIFT + VIDEO 4	Shift + 4
CD	CD	SHIFT + CD-STB 3	Shift + 3
TV	TV	SHIFT + TV 1	Shift + 1
DCC	DCC	SHIFT + DVD 2	Shift + 2
DSR	DSR	SHIFT + AUX-HDD 7	Shift + 7
DIG. REC	DIG. REC	SHIFT + USB 8	Shift + 8
A SPEAKERS	Speakers A	LIST SMART	Smart / List
SPEAKERS B	Speakers B	MEDIA DISPLAY	Display / Media
VOLUME AUDIO	Volume Audio +	+ VOL	Vol +
VOLUME AUDIO	Volume Audio -	VOL −	Vol -
VOLUME TV	Volume TV -	◀	Left
VOLUME TV	Volume TV +	▶	Right
AUDIO PROC −	Audio Processor	▼	Down
PROCESSOR +	Audio Processor	▲	Up

Original		Replacement	
1	VCR 1	TV 1	1
2	VCR 2	DVD 2	2
3	VCR 3	CD-STB 3	3
4	VCR 4	VIDEO 4	4
5	VCR 5	TAPE 5	5
6	VCR 6	TUNER 6	6
STANDBY	VCR Standby	⏻	Power
7	VCR 7	AUX-HDD 7	7
8	VCR 8	USB 8	8
9	VCR 9	BLUETOOTH 9	9
0	VCR 0	HDMI-SAT 0	0
VCR	VCR -/--	-/-- GUIDE EPG	Guide / EPG / -/--
MUTE	VCR Mute	DIMMER MUTE	Mute / Dimmer
PRESET TRACK	VCR Preset/Track	PRESET+ ⏭	>>I / Preset+
PRESET TRACK	VCR Preset/Track	PRESET- ⏮	I<< / Preset-
HOLD STOP	VCR Stop	HOLD ■	Stop / Hold
MEMO OUT PLAY	VCR Play	SLOW ▶	Play / Slow

Original	Replacement	Original	Replacement
VCR <<	<< / Tune-		
VCR Pause	Pause / Step / Freeze		
VCR >>	>> / Tune+		
VCR Record	Rec / Rec Mode		
VCR Mode	OK		
VCR Open/Close	Eject / Surround		
DIG. REC	Shift + Power		
DIG. REC Mute	Shift + Mute / Dimmer		
DIG. REC Preset/Track +	Shift + >>I / Preset+		
DIG. REC Preset/Track -	Shift + I<< / Preset-		
DIG. REC Stop	Shift + Stop /		
DIG. REC Pause	Shift + Pause / Step /		
DIG. REC <<	Shift + << /		
DIG. REC >>	Shift + >> /		
DIG. REC Mode	Shift + OK		
DIG. REC Play	Shift + Play /		
DIG. REC Open/Close	Shift + Eject / Surround		