Original	Replacement	Original	Replacement
Power	Power	Vol +	Vol +
Red/Disc	Red / Netflix / Search	Eject	Eject / Surround
Green/iPod/iPhor	Green / APP / Repeat	Stop	Stop / Hold
Yellow/Help	Yellow / YouTube / Repeat	Play	Play / Slow
Blue/♪ Source	Blue / Prime Video / Random	Pause	Pause / Step / Freeze
Home	Shift + Home Menu /	I<	I<< / Preset-
Pop-Up Menu/Disc Menu	Menu / Home	<<	<< / Tune-
Up	Up	>>	>> / Tune+
Sound Settings	Audio / Lang I/II	>I	>>I / Preset+
Left	Left	1	1
OK	OK	2	2
Right	Right	3	3
Back	Back / Return	4	4
Down	Down	5	5
Options	Setup / OPT /	6	6
Vol -	Vol -	7	7
Mute	Mute / Dimmer	8	8

Original		Replacement		Original	Replacement
WXYZ 9	9	BLUETOOTH 9	9		
TOP MENU	Top Menu	TOP MENU D.MENU	D. Menu / Top		
0	0	HDMI - SAT 0	0		
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ		