Mandis shop

Pioneer CU-DC014

Original		Replacement	
POWER	Power		Power
PHONO	Phono	LIST SMART	Smart / List
VOL-	Volume-	VOL −	Vol-
VOL+	Volume+	+ VOL	Vol+
CH PAGE	Tuner Station-	CH PAGE −	CH- / Page-
CH PAGE	Tuner Station+	+ CH PAGE	CH+ / Page+
PLAY ◀	< Play Deck II	SHIFT + ◀	Shift + Left
PLAY ▶	Play > Deck II	SHIFT + ▶	Shift + Right
PLAY ◀	< Play Deck I	◀	Left
PLAY ▶	Play > Deck I	▶	Right
FAST ◀◀	<< Fast Deck II	TUNE- ◀◀	<< / Tune-
FAST ▶▶	Fast >> Deck II	TUNE+ ▶▶	>> / Tune+
STOP	Stop Deck I	OK	OK
REC	Rec Deck II	REC MODE	Rec / Rec Mode
PAUSE	Pause Deck II	SHIFT + STEP - FREEZE	Shift + Pause / Step /
STOP	Stop Deck II	SHIFT + HOLD ■	Shift + Stop /
SLEEP	Timer Sleep	TIMER SLEEP	Sleep / Timer

Original		Replacement	
STOP	Stop CD	HOLD ■	Stop / Hold
DISC	Disc	Prime Video RANDOM	Blue / Prime Video / Random
PLAY ▶	Play CD	SLOW ▶	Play / Slow
SNOOZE	Snooze	MEDIA DISPLAY	Display / Media
PAUSE	Pause CD	STEP - FREEZE ⏸	Pause / Step / Freeze
TRACK SEARCH ◀◀	I<< Track Search	PRESET- ◀◀	I<< / Preset-
TRACK SEARCH ▶▶	Track Search >>I	PRESET+ ▶▶	>>I / Preset+

https://telecommandes-mandis.be/en/Pioneer/1067479-5482-replacement-remote-control-for-Pioneer-CU-DC014-AXD1088.html