Mandis shop

# Samsung DJ96-00114G

| Original | | Replacement | |
|---|---|---|---|
| Power | Power | Power | Power |
| Recharging | Recharging | Aspect / Eco | Eco / Aspect |
| Auto | Auto | Auto | Auto |
| Spot | Spot | Source | Source |
| Max | Max | Mode | Mode |
| | Up | | Up |
| | Right | | Right |
| | Left | | Left |
| Start/Stop | Start/Stop | Enter | Enter |
| Manual | Manual | Video / Comp | Comp / Video |
| Edge | Edge | Page▲ / Vol | Vol + / Page + |
| Clock | Clock | Menu | Menu |
| Timer/Daily | Timer/Daily | Timer / Freeze | Freeze / Timer |
| | No Name Left | Play | + / Play |
| | No Name Right | Focus / Volt | Volt / Focus |

| Original | Replacement |
|---|---|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

https://telecommandes-mandis.be/en/Samsung/1059728-79362-replacement-remote-control-for-Samsung-DJ96-00114G.html