Original	Replacement	Original	Replacement
Operate	Power	<<	<< / Tune-
Rec Mode	Text / Goto	Play	Play / Slow
VCR	Shift + 4	>>	>> / Tune+
DVD	Shift + 2	VCR Rec/OTR	Rec / Rec Mode
1	1	Stop	Stop / Hold
2	2	Audio	Audio / Lang I/II
3	3	Search	Red / Netflix / Search
Prog+	CH+ / Page+	I > Slow	Shift + Play /
4	4	Pause	Pause / Step / Freeze
5	5		
6	6		
Prog-	CH- / Page-		
7	7		
8	8		
9	9		
Clear/C. Reset	Exit / Cancel / Clear		
0	0		

Original		Replacement	
Operate		Power	
Dubbing		Info / Angle	
Setup		Setup / OPT /	
Open-Close/Eject		Eject / Surround	
T-Set		TV/Radio /	
Timer Prog./Showview		Sleep / Timer	
Rec Mode		Text / Goto	
Rapid Play		Smart / List	
Zoom		Zoom / Size	
VCR		Shift + 4	
DVD		Shift + 2	
CM Skip		Red / Netflix / Search	
Top Menu		D.Menu / Top	
Up		Up	
Menu/List		Menu / Home	
Return/Key		Back / Return	
Left		Left	

Original		Replacement	
Right		Right	
Down		Down	
Enter		OK	
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	
Skip >>I		>>I / Preset+	
Clear/C.Reset		Exit / Cancel / Clear	
0		0	
Display		Display / Media	
I<< Skip		I<< / Preset-	

Original		Replacement		Original		Replacement	
	<<	TUNE-	<< / Tune-				
PLAY	Play	SLOW	Play / Slow				
	>>	TUNE+	>> / Tune+				
STOP	Stop	HOLD	Stop / Hold				
DVD REC/OTR	DVD/Rec OTR	REC MODE	Rec / Rec Mode				
REPEAT	Repeat	APP / REPEAT	Green / APP / Repeat				
AUDIO	Audio	LANG I/II / AUDIO	Audio / Lang I/II				
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze				