Original		Replacement	
ON/STAND-BY	On/Standby		Power
OPEN/CLOSE	Open/Close	ZOOM	Eject
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
10+	10+	-/-- GUIDE	Guide
REPEAT	Back/Repeat	RETURN BACK	Back
MEMORY	Memory	HOME SMART	Smart
CLEAR	Clear	CLEAR EXIT	Exit
CLOCK/TIMER	Clock/Timer	TIMER AV	AV

Original		Replacement	
SLEEP	Sleep	PROG SLEEP	Sleep
BASS/TREBLE	Bass/Treble	SETTINGS OPT	Options
X-BASS	X-Bass	SOUND DUAL	Dual
RANDOM	Random	AD SUBT	Subt
TUNING	<<|<<|Tuning		<<
TUNING	>>|>>|Tuning		>>
FOLDER	Folder	REPEAT TEXT	Text
DEMO/DIMMER	Demo/Dimmer	DISPLAY INFO	Info
PRESET	Preset Up		Up
PRESET	Preset Down		Down
ENTER	Enter	OK	Ok
VOL	Vol+	+ VOL	Vol +
VOL	Vol-	VOL −	Vol -
	Mute	MUTE	Mute
CD	CD	C	Yellow
USB	USB	B	Green
TUNER	Tuner	D	Blue

Original		Replacement		Original	Replacement
AUDIO/LINE INPUT	Input/Audio/Line	A	Red		
iPod	iPod	ECO 3D	3D		
DISPLAY (TV OUT)	(Tv Out)/Display	SEARCH TV/R	TV/R		
MENU	Menu	TOP MENU MENU	Menu		
►/II	Play/Pause iPod	PLAY MODE ►	Play		
DISPLAY	Display CD/USB	►	Right		
■	Stop CD/USB	■	Stop		
►/II	Play/Pause	II	Pause		
ASPM	ASPM RDS	E-MANUAL D.MENU	D. Menu		
PTY	PTY RDS	PICTURE FORMAT	Format		
DISPLAY	Display RDS	◄	Left		
NETWORK	Network	APP MEDIA	Media		