Original	Replacement	Original	Replacement
Power	Power	>I	>>I / Preset+
Optical	1	>I	Right
Optical	Red / Netflix / Search	Vol-	Vol-
Mute	Mute / Dimmer	Vol-	Down
AUX	7	News	Audio / Lang I/II
AUX	Green / APP / Repeat	Movie	Picture / Format
BT	9	Music	Sound / Title
BT	Yellow / YouTube / Repeat		
HDMI ARC	0		
HDMI ARC	Blue / Prime Video / Random		
Vol+	Vol+		
Vol+	Up		
I<	I<< / Preset-		
I<	Left		
Play/Pause / Pai	OK		
Play/Pause / Pai	Play / Slow		
Play/Pause / Pai	Pause / Step / Freeze		

Original	Replacement	Original	Replacement
Power	Power		
Bluetooth	9		
Source	AV / Input / RDS		
Vol +	Vol +		
Vol -	Vol -		
Mute	Mute / Dimmer		
>>I	>>I / Preset+		
I<<	I<< / Preset-		
Play/Pause	Play / Slow		
Play/Pause	Pause / Step / Freeze		
Bass+	Right		
Bass-	Left		
EQ	Subtitle / EQ		
Tre+	Up		
Tre-	Down		