Original	Replacement	Original	Replacement
Power	Power	Up	Up
Source	AV / Input / RDS	Down	Down
1	1	Left	Left
2	2	Right	Right
3	3	OK	OK
4	4	Back	Back / Return
5	5	Home	Shift + Menu /
6	6	Exit	Exit / Cancel / Clear
7	7	Vol +	Vol +
8	8	Vol -	Vol -
9	9	CH+	CH+ / Page+
0	0	CH-	CH- / Page-
Mute	Mute / Dimmer	Netflix	Shift + Red / Netflix /
Guide	Guide / EPG / -/--	prime video	Shift + Blue / Prime
Menu	Menu / Home	YouTube	Shift + Yellow / YouTube /
Smart Colors	Smart / List	FPlay	Shift + Green / APP /
Info	Info / Angle	Audio	Audio / Lang I/II

Original		Replacement		Original	Replacement
SUB	Sub	EQ SUBTITLE	Subtitle / EQ		
TEXT	Text	GOTO TEXT	Text / Goto		
TV	TV	PROGRAM TV/ RADIO	TV/ Radio /		
▶II	Play	SLOW ▶	Play / Slow		
▶II	Pause	STEP - FREEZE II	Pause / Step / Freeze		
◀◀	<<	TUNE- ◀◀	<< / Tune-		
▶▶	>>	TUNE+ ▶▶	>> / Tune+		
■	Stop	HOLD ■	Stop / Hold		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		