Original		Replacement	
OPERATE	Operate		Power
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
PROGRAM	Program	PROGRAM TV/RADIO	TV/Radio /
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
A-B	A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat
TIME	Time	TIMER SLEEP	Sleep / Timer
SLOW/SE	<< Slow/Search	TUNE-	<< / Tune-
/SEARCH	Slow/Search >>	TUNE+	>> / Tune+
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
SKIP/FR	I<< Skip/Frame	PRESET-	I<< / Preset-
/FRAME	Skip/Frame >>I	PRESET+	>>I / Preset+
PLAY/PAUSE	Play/Pause	SLOW	Play / Slow
PLAY/PAUSE	Play/Pause	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
TITLE	Title	TITLE SOUND	Sound / Title
MENU	Menu	HOME MENU	Menu / Home
DISPLAY	Display	MEDIA DISPLAY	Display / Media

Original		Replacement	
RETURN	Return	RETURN BACK	Back / Return
	Up		Up
	Left		Left
SELECT	Select	OK	OK
	Right		Right
SEARCH MODE	Search Mode	NETFLIX SEARCH	Red / Netflix / Search
	Down		Down
ANGLE	Angle	ANGLE INFO	Info / Angle
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7

Original		Replacement		Original	Replacement
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--		
0	0	HDMI - SAT 0	0		
C	C	CLEAR EXIT CANCEL	Exit / Cancel / Clear		