Original		Replacement	
	Power		Power
	Stereo/Mono	SHIFT +	TITLE SOUND Shift + Sound / Title
	Tv/Video	PROGRAM TV/RADIO	TV/Radio /
	Memory	LIST SMART	Smart / List
	Muting	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
	Function	OPT-TOOLS SETUP	Setup / OPT /
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
	Band	LANG I/II AUDIO	Audio / Lang I/II
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
	Sound/Field	TITLE SOUND	Sound / Title

Original		Replacement	
10/0	0/10	HDMI - SAT 0	0
10/0	+10	-/-- GUIDE EPG	Guide / EPG / -/--
	Display	MEDIA DISPLAY	Display / Media
	Vol+	+ VOL	Vol+
	Vol-	VOL −	Vol-
	Tv CH-	CH PAGE −	CH- / Page-
	Tv CH+	+ CH PAGE	CH+ / Page+
ENTER	Enter	OK	OK
AMP MENU	AMP Menu	HOME MENU	Menu / Home

Original		Replacement	
	Power		Power
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
PLAY MODE	Play Mode	SLOW	Play / Slow
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
TUNING- SLOW	<<</Tuning-/<I	TUNE-	<< / Tune-
TUNING+ SLOW	Tuning+/Slow	TUNE+	>> / Tune+
TV CH PRESET- PREV	I<<</Preset-	PRESET-	I<< / Preset-
TV CH PRESET+ NEXT	>>I/Preset+	PRESET+	>>I / Preset+
SOUND FIELD	Sound Field	TITLE SOUND	Sound / Title
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
BAND	Band	FORMAT PICTURE	Picture / Format
NAME	Name	SIZE ZOOM	Zoom / Size
TIME	Time	TIMER SLEEP	Sleep / Timer
TV/VIDEO	Tv/Video	PROGRAM TV/RADIO	TV/Radio / Program

Original		Replacement	
DVD MENU	DVD Menu	TOP MENU D.MENU	D.Menu / Top
FUNCTION	Function	OPT-TOOLS SETUP	Setup / OPT /
AMP MENU	AMP Menu	HOME MENU	Menu / Home
	Up		Up
ANGLE	Angle	ANGLE INFO	Info / Angle
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
VOL +	Vol+	+ VOL	Vol+
MEMORY	Memory	LIST SMART	Smart / List
VOL −	Vol-	VOL −	Vol-
DISPLAY	Display	MEDIA DISPLAY	Display / Media
1	1	TV 1	1
2	2	DVD 2	2

Original		Replacement		Original	Replacement
3	3	CD-STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX-HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
10/0	+10	-/-- GUIDE EPG	Guide / EPG / -/--		
10/0	0/10	HDMI-SAT 0	0		
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat		
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer		
PLAY/SELECT	Play/Select	SHIFT + SLOW ▶	Shift + Play /		
TITLE	Title	SHIFT + TITLE SOUND	Shift + Sound / Title		
STEREO/MONO	Stereo/Mono	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II		
ENTER	Enter	SHIFT + OK	Shift + OK		
DVD DISPLAY	DVD Display	SHIFT + DVD 2	Shift + 2		
DVD SETUP	DVD Setup	SHIFT + CD-STB 3	Shift + 3		