Original	Replacement	Original	Replacement
Power	Power	Menu	Menu
Mute	Mute	[I I I]	Subt
[O]	SHIFT + TIMER AV Shift + AV	1	1
[i +]	DISPLAY INFO Info	2	2
[ ]	APP MEDIA Media	3	3
[≡]	REPEAT TEXT Text	4	4
Input / [+]	TIMER AV AV	5	5
Output / [?]	SEARCH TV/R TV/R	6	6
[><]	SETTINGS OPT Options	7	7
[I <>]	PICTURE FORMAT Format	8	8
↔>	HOME SMART Smart	9	9
[+]	ECO 3D 3D	0	0
[*] / [I I	DISC NAV LIST List	-/--	Guide
[/] / [↔]	ZOOM ⏏ Eject	C	Pre Ch
[←]	RETURN BACK Back	Progr +	Ch +
↑	CLEAR EXIT Exit	Prog -	Ch -
♪	SOUND DUAL Dual	Vol +	Vol +

Original	Replacement	Original	Replacement
Vol -	Vol -	CH + VTR 1	Shift + Ch +
Up	Up	CH - VTR 1	Shift + Ch -
Down	Down		
Right	Right		
Left	Left		
OK	Ok		
Red	Red		
Green	Green		
Yellow	Yellow		
Blue	Blue		
Power VTR 1	Shift + Power		
>> VTR 1	>>		
Play VTR 1	Play		
<< VTR 1	<<		
Stop VTR 1	Stop		
Pause VTR 1	Pause		
Rec VTR 1	Rec		

Original	Replacement	Original	Replacement
Power Video VTR	Power		
>> VTR 2	>>		
<< VTR 2	<<		
Play VTR 2	Play		
Stop VTR 2	Stop		
Pause VTR 2	Pause		
Rec VTR 2	Rec		
CH + VTR 2	Ch +		
CH - VTR 2	Ch -		

Original		Replacement		Original	Replacement
VIDEO	Power Video VTR		Power		
	>> VTR 3		>>		
	<< VTR 3		<<		
	Play VTR 3	PLAY MODE	Play		
	Stop VTR 3		Stop		
	Pause VTR 3		Pause		
REC	Rec VTR 3	REC MODE	Rec		
CH +	CH + VTR 3	CH +	Ch +		
CH -	CH - VTR 3	CH -	Ch -		

Original	Replacement	Original	Replacement
Power Video	Power		
>> MDP	>>		
<< MDP	<<		
Play MDP	Play		
Pause MDP	Pause		
Stop MDP	Stop		
Rec MDP	Rec		
CH + MDP	Ch +		
CH - MDP	Ch -		