| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | Power AV | SHIFT + | Shift + Power |
| | Auto Cal | HOME SMART | Smart |
| | Sleep | PROG SLEEP | Sleep |
| | MD-TAPE | APP MEDIA | Media |
| | AMP MENU | TOP MENU MENU | Menu |
| | 2CH | A | Red |
| | A.F.D. | B | Green |
| | Movie | C | Yellow |
| | Music | D | Blue |
| | 1 | 1 | 1 |
| | 2 | 2 | 2 |
| | 3 | 3 | 3 |
| | 4 | 4 | 4 |
| | 5 | 5 | 5 |
| | 6 | 6 | 6 |
| | 7 | 7 | 7 |

| Original | | Replacement | |
|---|---|---|---|
| | 8 | 8 | 8 |
| | 9 | 9 | 9 |
| | 0/10 | 0 | 0 |
| | >10/* -/-- CLEAR | -/-- GUIDE | Guide |
| | DUAL MONO | SOUND DUAL | Dual |
| | FM MODE | SEARCH TV/R | TV/R |
| | DISPLAY | DISPLAY INFO | Info |
| | Up AMP Menu | | Up |
| | Down AMP | | Down |
| | Right AMP Menu | | Right |
| | Left AMP Menu | | Left |
| | OK MD/Tape | SHIFT + OK | Shift + Ok |
| | OK AMP Menu | OK | Ok |
| | TV VOL MASTER VOL + | + VOL | Vol + |
| | Vol - | VOL – | Vol - |
| | MUTING | MUTE | Mute |
| | TV CH – PRESET – | << | I<< |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| TV CH + PRESET + | >>I / Preset + | >>I | >>I | | |
| TUNING – | <<I Tuning- | << | << | | |
| | Play | PLAY MODE ▶ | Play | | |
| TUNING + | >>I Tuning+ | >> | >> | | |
| | Pause | II | Pause | | |
| | Stop | ■ | Stop | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | Power AV | SHIFT + | Shift + Power |
| | Auto Cal | HOME SMART | Smart |
| | Sleep | PROG SLEEP | Sleep |
| | 2CH | A | Red |
| | A. F. D. | B | Green |
| | Movie | C | Yellow |
| | Music | D | Blue |
| | 1 | 1 | 1 |
| | 2 | 2 | 2 |
| | 3 | 3 | 3 |
| | 4 | 4 | 4 |
| | 5 | 5 | 5 |
| | 6 | 6 | 6 |
| | 7 | 7 | 7 |
| | 8 | 8 | 8 |
| | 9 | 9 | 9 |

| Original | | Replacement | |
|---|---|---|---|
| | 0/10 | 0 | 0 |
| | >10/* -/-- CLEAR | -/-- GUIDE | Guide |
| | MEMORY ENTER | FAV PRE-CH | Pre Ch |
| | Menu | TOP MENU MENU | Menu |
| | DVD Menu | E-MANUAL D.MENU | D. Menu |
| | Return/Exit | CLEAR EXIT | Exit |
| | Tools | SETTINGS OPT | Options |
| | Display | DISPLAY INFO | Info |
| | D.Tuning/D.Skip | PICTURE FORMAT | Format |
| | FM Mode | SEARCH TV/R | TV/R |
| | Dual Mono | SOUND DUAL | Dual |
| | Muting | MUTE | Mute |
| | Vol + | + VOL | Vol + |
| | Vol - | VOL – | Vol - |
| | OK | OK | Ok |
| | Up | | Up |
| | Down | | Down |

| Original | | Replacement | |
|---|---|---|---|
| | Right | | Right |
| | Left | | Left |
| | Play | PLAY MODE | Play |
| | Pause | | Pause |
| | Stop | | Stop |
| TUNING – | <</ Tuning- | | << |
| TUNING + | >>/ Tuning+ | | >> |
| TV CH + PRESET + | >>I / Preset + | | >>I |
| TV CH – PRESET – | I <</ Preset - | | I << |
| REPLAY | ← / Replay | CH – | Ch - |
| ADVANCE | · →/ Advance | + CH | Ch + |
| DVD | DVD | APP MEDIA | Media |
| D.TUNING D.SKIP | D. Tuning/ D. Skip Tuner | ECO 3D | 3D |
| TUNER | Tuner | SHIFT + APP MEDIA | Shift + Media |
| MEMORY ENTER | Enter / Memory | SHIFT + FAV PRE-CH | Shift + Pre Ch |
| 1 | 1 Tuner | SHIFT + 1 | Shift + 1 |
| 2 | 2 Tuner | SHIFT + 2 | Shift + 2 |

| Original | | Replacement | |
|---|---|---|---|
| 3 | 3 Tuner | SHIFT + 3 | Shift + 3 |
| 4 | 4 Tuner | SHIFT + 4 | Shift + 4 |
| 5 | 5 Tuner | SHIFT + 5 | Shift + 5 |
| 6 | 6 Tuner | SHIFT + 6 | Shift + 6 |
| 7 | 7 Tuner | SHIFT + 7 | Shift + 7 |
| 8 | 8 Tuner | SHIFT + 8 | Shift + 8 |
| 9 | 9 Tuner | SHIFT + 9 | Shift + 9 |
| 0/10 | 0/ 10 Tuner | SHIFT + 0 | Shift + 0 |
| DISPLAY | Display Tuner | SHIFT + DISPLAY INFO | Shift + Info |
| | OK Tuner | SHIFT + OK | Shift + Ok |
| | Up Tuner | SHIFT + | Shift + Up |
| | Down Tuner | SHIFT + | Shift + Down |
| | Right Tuner | SHIFT + | Shift + Right |
| | Left Tuner | SHIFT + | Shift + Left |
| TUNING – | <</ Tuning- Tuner | SHIFT + | Shift + << |
| TUNING + | >>/ Tuning+ | SHIFT + | Shift + >> |
| TV CH – PRESET – | I <</ Preset - / Tv CH- Tuner | SHIFT + | Shift + I << |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| TV CH + PRESET + >>I / Preset +/ Tv CH+ Tuner | SHIFT + >>I Shift + >>I | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | Play | PLAY MODE | Play |
| | Stop | | Stop |
| AUTO CAL | Auto Cal | HOME SMART | Smart |
| TV/VIDEO SLEEP | Sleep | PROG SLEEP | Sleep |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0/10 | 0/10 | 0 | 0 |
| >10/* -/-- CLEAR | -/--/>10 | -/-- GUIDE | Guide |
| | OK | OK | Ok |

| Original | | Replacement | |
|---|---|---|---|
| MEMORY ENTER | Enter/Memory | FAV PRE-CH | Pre Ch |
| MENU | Menu | TOP MENU MENU | Menu |
| DISPLAY | Display | DISPLAY INFO | Info |
| MUTING | Muting | MUTE | Mute |
| TV VOL MASTER VOL + | Vol + | + VOL | Vol + |
| – | Vol - | VOL – | Vol - |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| DUAL MONO | Dual Mono | SOUND DUAL | Dual |
| FM MODE | FM Mode | PICTURE FORMAT | Format |
| 2CH | 2CH | A | Red |
| A.F.D. | A. F. D. | B | Green |
| MOVIE | Movie | C | Yellow |
| MUSIC | Music | D | Blue |
| | Pause | | Pause |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| TUNING + | >>/ Tuning+ | >> | | | |
| TUNING – | <<| Tuning- | << | | | |
| TV CH + PRESET + | >>| / Preset + | >>| | | | |
| TV CH – PRESET – | |<<| Preset - | |<< | | |
| REPLAY | ← / Replay | CH – | Ch - | | |
| ADVANCE | · →/ Advance | + CH | Ch + | | |
| VIDEO 3 | Video 3 | SHIFT + APP MEDIA | Shift + Media | | |
| VIDEO 1 | Video 1 | APP MEDIA | Media | | |
| AV I/⏻ SYSTEM | Power AV | TIMER AV | AV | | |
| TV I/⏻ STANDBY | Tv Power | SHIFT + ⏻ | Shift + Power | | |
| TV/VIDEO SLEEP | Tv/ Video | SEARCH TV/R | TV/ R | | |
| TV VOL MASTER VOL + | Tv Vol + | SHIFT + + VOL | Shift + Vol + | | |
| – | Tv Vol - | SHIFT + VOL – | Shift + Vol - | | |
| TV CH – PRESET – | Tv CH- | SHIFT + CH – | Shift + Ch - | | |
| TV CH + PRESET + | Tv CH+ | SHIFT + + CH | Shift + Ch + | | |
| | | | | | |
| | | | | | |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power | Power | -/--/>10 | Guide |
| Power AV | SHIFT + Power | Enter/Memory | Pre Ch |
| Auto Cal | Smart | FM Mode | TV/R |
| Sleep | Sleep | Dual Mono | Dual |
| A.F.D. | Green | Display | Info |
| Movie | Yellow | Muting | Mute |
| Music | Blue | Vol + | Vol + |
| 1 | 1 | Vol - | Vol - |
| 2 | 2 | Menu | Menu |
| 3 | 3 | OK | Ok |
| 4 | 4 | Up | Up |
| 5 | 5 | Down | Down |
| 6 | 6 | Right | Right |
| 7 | 7 | Left | Left |
| 8 | 8 | Play | Play |
| 9 | 9 | Pause | Pause |
| 0/10 | 0 | Stop | Stop |

| Original | | Replacement | |
|---|---|---|---|
| TUNING – | <</ Tuning- | « | << |
| TUNING + | >>/ Tuning+ | » | >> |
| TV CH + PRESET + | >>I / Preset + | »I | >>I |
| TV CH – PRESET – | I <</ Preset - | «I | I << |
| REPLAY | ← / Replay | CH – | Ch - |
| ADVANCE | · →/ Advance | + CH | Ch + |
| VIDEO 2 | Video 2 | APP MEDIA | Media |
| SA-CD/CD | SA- CD/ CD | SHIFT + APP MEDIA | Shift + Media |
| AV I/⏻ SYSTEM | Power AV | TIMER AV | AV |
| 2CH | 2CH | A | Red |
| D.TUNING D.SKIP | D. Tuning/ D. Skip SA- CD/ CD | PICTURE FORMAT | Format |
| MEMORY ENTER | Enter/ Memory SA- CD/ CD | SHIFT + FAV PRE-CH | Shift + Pre Ch |
| 1 | 1 SA- CD/ CD | SHIFT + 1 | Shift + 1 |
| 2 | 2 SA- CD/ CD | SHIFT + 2 | Shift + 2 |
| 3 | 3 SA- CD/ CD | SHIFT + 3 | Shift + 3 |
| 4 | 4 SA- CD/ CD | SHIFT + 4 | Shift + 4 |
| 5 | 5 SA- CD/ CD | SHIFT + 5 | Shift + 5 |

| Original | | Replacement | |
|---|---|---|---|
| 6 | 6 SA- CD/ CD | SHIFT + 6 | Shift + 6 |
| 7 | 7 SA- CD/ CD | SHIFT + 7 | Shift + 7 |
| 8 | 8 SA- CD/ CD | SHIFT + 8 | Shift + 8 |
| 9 | 9 SA- CD/ CD | SHIFT + 9 | Shift + 9 |
| 0/10 | 0/ 10 SA- CD/ CD | SHIFT + 0 | Shift + 0 |
| >10/• -/-- CLEAR | -/--/>10 SA- CD/ CD | SHIFT + -/-- GUIDE | Shift + Guide |
| DISPLAY | Display SA- CD/ CD | SHIFT + DISPLAY INFO | Shift + Info |
| ■ | Stop SA- CD/ CD | SHIFT + ■ | Shift + Stop |
| II | Pause | SHIFT + II | Shift + Pause |
| ▷ | Play SA- CD/ CD | SHIFT + PLAY MODE ▶ | Shift + Play |
| TUNING – | <</ Tuning- | SHIFT + « | Shift + << |
| TUNING + | >>/ Tuning+ | SHIFT + » | Shift + >> |
| TV CH – PRESET – | I <</ Preset - SA- CD/ CD | SHIFT + «I | Shift + I << |
| TV CH + PRESET + | >>I / Preset + SA- CD/ CD | SHIFT + »I | Shift + >>I |