Mandis shop

Sony RM-S171

Original		Replacement	
	Power		Power
	Display	DISPLAY INFO	Info
	DSG	ZOOM	Eject
	Play CD	PLAY MODE	Play
	Pause CD		Pause
	Stop CD		Stop
	Play	SHIFT + PLAY MODE	Shift + Play
	I<</- Tuner		I<<
	>>I/+ Tuner		>>I
	Play/<> Tape	SETTINGS OPT	Options
	<< Tape		<<
	>> Tape		>>
	Play Dir Mode	HOME SMART	Smart
	FM Mode	SOUND DUAL	Dual
	Rec	REC MODE	Rec
	CD Repeat	REPEAT TEXT	Text
	Function	TOP MENU MENU	Menu

Original		Replacement	
	Tuning Mode/Play Mode	PICTURE FORMAT	Format
	Up/Memory		Up
	Down/Sleep		Down
	Right/Timer		Right
	Left/Timer Set		Left
	Enter/On/Off	OK	Ok
	Vol+	+ VOL	Vol +
	Vol-	VOL −	Vol -

https://telecommandes-mandis.be/en/Sony/1058653-5964-replacement-remote-control-for-Sony-RM-S171-147723911.html