Mandis shop

Sony RM-SC30

Original		Replacement	
	Power		Power
	Sleep	PROG SLEEP	Sleep
	Display	DISPLAY INFO	Info
	Select	-/-- GUIDE	Guide
	Set Clock/Timer	FAV PRE-CH	Pre Ch
	Tuner Memory	REC MODE	Rec
	Audio In	A	Red
	Play Mode/Tuning Mode	SHIFT + PLAY MODE	Shift + Play
	CD	C	Yellow
	Repeat/FM	REPEAT TEXT	Text
	Band/Tuner	B	Green
	Function	TOP MENU MENU	Menu
	I<<		I<<
	>>I		>>I
	<<		<<
	>>		>>
	Play	PLAY MODE	Play

Original		Replacement	
	Pause		Pause
	Stop		Stop
ENTER	Enter	OK	Ok
VOLUME	Vol+	+ VOL	Vol +
VOLUME	Vol-	VOL −	Vol -
	Folder +	+ CH	Ch +
	Folder -	CH −	Ch -
CLEAR	Clear	CLEAR EXIT	Exit
EQ	EQ	SETTINGS OPT	Options

https://telecommandes-mandis.be/en/Sony/1062939-6157-replacement-remote-control-for-Sony-RM-SC-31-A1237274A.html