Mandis shop

RM-SCEX1

Original		Replacement	
	Power		Power
	Play CD	SLOW	Play / Slow
	Pause CD	STEP · FREEZE	Pause / Step / Freeze
	Stop CD	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I<</-	PRESET-	I<< / Preset-
	>>I/+	PRESET+	>>I / Preset+
	Stereo/Mono	LANG I/II AUDIO	Audio / Lang I/II
	Open/Close	SURROUND	Eject / Surround
	Tuning Mode	FORMAT PICTURE	Picture / Format
	Tuner/Band	PROGRAM TV/ RADIO	TV/Radio /
	Function	HOME MENU	Menu / Home
	Up/Memory		Up
	Left/Timer Set		Left
	Enter/On/Off	OK	OK
	Right/Timer		Right

Original		Replacement	
	Down/Sleep		Down
	Vol+	VOL	Vol+
	DSG	LIST SMART	Smart / List
	Vol-	VOL	Vol-
	Display	MEDIA DISPLAY	Display / Media
	Repeat	APP REPEAT	Green / APP / Repeat
	Play Mode	Prime Video RANDOM	Blue / Prime Video / Random
	Surround	SHIFT + SURROUND	Shift + Eject / Surround

Select

https://telecommandes-mandis.be/en/Sony/1066154-95747-replacement-remote-control-for-Sony-RM-SCEX1.html