Original		Replacement	
	Power		Power
SUB-T	Sub-T	EQ SUBTITLE	Subtitle / EQ
LANG	Lang	LANG I/II AUDIO	Audio / Lang I/II
	Mute	DIMMER MUTE	Mute / Dimmer
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
GOTO	Goto	SHIFT + GOTO TEXT	Shift + Text /
PAGE+	Page+	+ CH PAGE	CH+ / Page+
TTX	TTX	GOTO TEXT	Text / Goto
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
PAGE-	Page-	CH PAGE –	CH- / Page-
MENU	Menu	HOME MENU	Menu / Home
CH+	Up/CH+		Up
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
VOL-	Left		Left
VOL-	Vol-	VOL –	Vol-
OK	OK	OK	OK
VOL+	Right		Right

Original		Replacement	
VOL+	Vol+	+ VOL	Vol+
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
CH-	Down/CH-		Down
TV/RADIO	Tv/Radio	PROGRAM TV/ RADIO	TV/Radio /
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
RECALL	Recall	RETURN BACK	Back / Return
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
INFO	Info	ANGLE INFO	Info / Angle
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
	<<	TUNE-	<< / Tune-

Original		Replacement	
	>>	TUNE+	>> / Tune+
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
	Play	SLOW	Play / Slow
TIMESHIFT	Pause/Timeshift	STEP - FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
	Rec	REC MODE	Rec / Rec Mode
PVR	Red/PVR	NETFLIX SEARCH	Red / Netflix / Search
V-FORMAT	Green/V-Format	APP REPEAT	Green / APP / Repeat
ASPECT	Yellow/Aspect	YouTube REPEAT A-B	Yellow / YouTube / Repeat
TIMER	Blue/Timer	Prime Video RANDOM	Blue / Prime Video / Random

Original	Replacement