Original		Replacement	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
0	0	HDMI - SAT 0	0
	Recall	RETURN BACK	Back / Return
ASPECT	Aspect	SHIFT + FORMAT PICTURE	Shift + Picture / Format
SOUND	Sound	TITLE SOUND	Sound / Title
APP	APP	MEDIA DISPLAY	Display / Media

Original		Replacement	
VOL +	Vol +	VOL +	Vol +
	Home	SHIFT + HOME MENU	Shift + Menu /
	Home	TOP MENU D.MENU	D. Menu / Top
CH +	CH+	CH + PAGE	CH+ / Page+
VOL −	Vol -	VOL −	Vol -
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
CH −	CH-	CH − PAGE	CH- / Page-
PICTURE	Picture	FORMAT PICTURE	Picture / Format
TV	TV	SHIFT + TV 1	Shift + 1
TV	TV	PROGRAM TV/ RADIO	TV/ Radio /
USB	USB	SHIFT + USB 8	Shift + 8
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
	Left		Left
OK	OK	OK	OK
	Right		Right

Original		Replacement		Original		Replacement	
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear	EQ	Text Subpage	SURROUND	Eject / Surround
▼	Down	▼	Down		Text Reveal	SHIFT + SLOW ▶	Shift + Play /
INFO	Info / Text Inde	ANGLE INFO	Info / Angle		Text Size	SIZE ZOOM	Zoom / Size
◀◀	Red / <<	TUNE- ◀◀	<< / Tune-	FAV	FAV	PC FAV MARKER	Fav / Marker / PC
◀◀	Red / <<	NETFLIX SEARCH	Red / Netflix / Search	SUB	SUB	EQ SUBTITLE	Subtitle / EQ
▶▶	Green / >>	TUNE+ ▶▶	>> / Tune+	LIST	List	LIST SMART	Smart / List
▶▶	Green / >>	APP REPEAT	Green / APP / Repeat				
⏮	Yellow / I<<	PRESET- ⏮	I<< / Preset-				
⏮	Yellow / I<<	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
⏭	Blue / >>I	PRESET+ ⏭	>>I / Preset+				
⏭	Blue / >>I	Prime Video RANDOM	Blue / Prime Video / Random				
▶II	Play / Pause	SLOW ▶	Play / Slow				
■	Stop	HOLD ■	Stop / Hold				
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /				
≡	Text	GOTO TEXT	Text / Goto				
≡	Text Hold	SHIFT + HOLD ■	Shift + Stop /				
≡	Text Cancel	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear				

Original		Replacement	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
0	0	HDMI - SAT 0	0
	Recall	RETURN BACK	Back / Return
ASPECT	Aspect	OPT-TOOLS SETUP	Setup / OPT /
ASPECT	Aspect	SHIFT + FORMAT PICTURE	Shift + Picture / Format
SOUND	Sound	TITLE SOUND	Sound / Title

Original		Replacement	
APP	APP	MEDIA DISPLAY	Display / Media
+ VOL	Vol +	+ VOL	Vol +
	Home	SHIFT + HOME MENU	Shift + Menu /
	Home	TOP MENU D.MENU	D. Menu / Top
+ CH	CH+	+ CH PAGE	CH+ / Page+
VOL −	Vol -	VOL −	Vol -
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
CH −	CH-	CH PAGE −	CH- / Page-
PICTURE	Picture	FORMAT PICTURE	Picture / Format
TV	TV	PROGRAM TV/ RADIO	TV/ Radio /
TV	TV	SHIFT + TV 1	Shift + 1
USB	USB	SHIFT + USB 8	Shift + 8
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
	Left		Left
OK	OK	OK	OK

Original		Replacement	
	Right		Right
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down		Down
INFO	Info / Text Inde	ANGLE INFO	Info / Angle
	Red / <<	TUNE-	<< / Tune-
	Red / <<	NETFLIX SEARCH	Red / Netflix / Search
	Green / >>	TUNE+	>> / Tune+
	Green / >>	APP REPEAT	Green / APP / Repeat
	Yellow / I<<	PRESET-	I<< / Preset-
	Yellow / I<<	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue / >>I	PRESET+	>>I / Preset+
	Blue / >>I	Prime Video RANDOM	Blue / Prime Video / Random
	Play/Pause	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
	Text	GOTO TEXT	Text / Goto
	Text Hold	SHIFT + HOLD	Shift + Stop / Hold

Original		Replacement	
	Text Cancel	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
	Text Subpage	SURROUND	Eject / Surround
	Text Reveal	SHIFT + SLOW	Shift + Play /
	Text Size	SIZE ZOOM	Zoom / Size
FAV	Fav	PC FAV MARKER	Fav / Marker / PC
SUB	SUB	EQ SUBTITLE	Subtitle / EQ
LIST	List	LIST SMART	Smart / List