| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power | Power | Music/Photo/Cam | 3D |
| Mute | Mute | EPG | Guide |
| Tv/Radio | TV/R | Vol + | Vol + |
| FAV | Pre Ch | Vol - | Vol - |
| World/Internet | Smart | CH+ | Ch + |
| 1 | 1 | CH- | Ch - |
| 2 | 2 | Exit | Exit |
| 3 | 3 | Info | Info |
| 4 | 4 | Back | Back |
| 5 | 5 | Menu | Menu |
| 6 | 6 | OK | Ok |
| 7 | 7 | Up | Up |
| 8 | 8 | Down | Down |
| 9 | 9 | Right | Right |
| 0 | 0 | Left | Left |
| LIB | List | Stop | Stop |
| P: P | AV | Play | Play |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| | Rec | REC MODE | Rec | | | | |
| | Pause | | Pause | | | | |
| | >> | | >> | | | | |
| | << | | << | | | | |
| TEXT | Text | REPEAT TEXT | Text | | | | |
| SUBT. | Subt. | AD SUBT | Subt | | | | |
| AUDIO | Audio | SOUND DUAL | Dual | | | | |
| OPT | OPT | SETTINGS OPT | Options | | | | |
| | Red | A | Red | | | | |
| | Green | B | Green | | | | |
| | Yellow | C | Yellow | | | | |
| | Blue | D | Blue | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |