Original		Replacement	
	Power		Power
MUTE	Mute	MUTE	Mute
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
	<<		<<
	>>		>>
	I<<		I<<
	>>I		>>I
	Play	PLAY MODE	Play
	Pause		Pause
	Stop		Stop
MEDIA	Media	APP MEDIA	Media
SUBTITLE	Subtitle	AD SUBT	Subt
TTX	TTX	REPEAT TEXT	Text
AUDIO	Audio	SOUND DUAL	Dual

Original		Replacement	
EPG	EPG	GUIDE	Guide
MENU	Menu	TOP MENU MENU	Menu
INFO	Info	DISPLAY INFO	Info
	Up		Up
	Left		Left
OK	OK	OK	Ok
	Right		Right
	Down		Down
FAV	FAV	FAV PRE-CH	Pre Ch
EXIT	Exit	CLEAR EXIT	Exit
VOL +	Vol+	VOL +	Vol +
VOL -	Vol-	VOL -	Vol -
REC	Rec	REC MODE	Rec
USB	USB	HOME SMART	Smart
USB	USB	TIMER AV	AV
CH +	CH+	CH +	Ch +
CH -	CH-	CH -	Ch -

Original		Replacement		Original	Replacement
1	1	1	1		
2	2	2	2		
3	3	3	3		
4	4	4	4		
5	5	5	5		
6	6	6	6		
7	7	7	7		
8	8	8	8		
9	9	9	9		
0	0	0	0		
BACK	Back	RETURN BACK	Back		
TV/RADIO	TV/Radio	SEARCH TV/R	TV/R		