Mandis shop

Yamaha VK380100

Original		Replacement	
PHONO	Phono	1	1
PLAY/CUT	Play/Cut Phono	7	7
AUX	AUX	6	6
CD	CD	2	2
PLAY	Play CD	PLAY MODE ▶	Play
SKIP	I<< Skip CD	<<	I<<
SKIP	>>I Skip CD	>>	>>I
SEARCH	<< Search CD	<<	<<
SEARCH	>> Search CD	>>	>>
PAUSE/STOP	Pause/Stop CD	II	Pause
PAUSE/STOP	Pause/Stop CD	■	Stop
DISC SKIP	Disc Skip CD	DISC NAV LIST	List
TUNER	Tuner	3	3
A/B/C/D/E	A/B/C/D/E Tuner	HOME SMART	Smart
PRESET -	Preset - Tuner	CH −	Ch -
PRESET +	Preset + Tuner	+ CH	Ch +
EQ ON/FLAT	EQ On/Flat	TOP MENU MENU	Menu

Original		Replacement	
EQ PRESET +	EQ Preset+	E-MANUAL D.MENU	D. Menu
TAPE 1/DAT	Tape 1	4	4
TAPE 2	Tape 2	5	5
TAPE 1/2 PLAY	Play Tape	OK	Ok
DIR A	Dir A Tape	A	Red
DIR B	Dir B Tape	B	Green
<<	<< Tape	◀	Left
>>	>> Tape	▶	Right
STOP	Stop Tape	▼	Down
DECK A/B	Deck A/B Tape	C	Yellow
REC/PAUSE	Rec/Pause Tape	▲	Up
REC MUTE	Rec Mute Tape	MUTE	Mute
VOLUME −	Vol-	VOL −	Vol -
VOLUME +	Vol+	+ VOL	Vol +

https://telecommandes-mandis.be/en/Yamaha/1063858-79158-replacement-remote-control-for-Yamaha-AX-VK380100.html