Original		Replacement	
STANDBY	Standby		Power
AUTO	Auto	OPT-TOOLS SETUP	Setup / OPT /
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
-/--	-/--	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
0	0	HDMI - SAT 0	0
	Recall	RETURN BACK	Back / Return
+ VOL	Vol+	+ VOL	Vol+
ASPECT	Aspect	SHIFT + FORMAT PICTURE	Shift + Picture / Format

Original		Replacement	
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
+ CH	CH+	+ CH PAGE	CH+ / Page+
VOL −	Vol-	VOL −	Vol-
DISPLAY	Display	MEDIA DISPLAY	Display / Media
CH −	CH-	CH PAGE −	CH- / Page-
▲	Up	▲	Up
◀	Left	◀	Left
ENTER	Enter	OK	OK
▶	Right	▶	Right
MENU	Menu	HOME MENU	Menu / Home
▼	Down	▼	Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
INPUT	Input	RDS AV INPUT	AV / Input / RDS
PMODE	P.Mode	FORMAT PICTURE	Picture / Format
SMODE	S.Mode	TITLE SOUND	Sound / Title
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
FAV-	Fav	PC FAV MARKER	Fav / Marker / PC

Original		Replacement	
FAV-	Fav-	SHIFT + ▼	Shift + Down
FAV+	Fav+	SHIFT + ▲	Shift + Up
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
TEXT	Text	GOTO TEXT	Text / Goto
CH.List	CH List	LIST SMART	Smart / List
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
TV/RADIO	TV / Radio	PROGRAM TV/ RADIO	TV/Radio /
MEDIA	Media	SHIFT + MEDIA DISPLAY	Shift + Display / Media
▶II	Play / Pause	SLOW ▶	Play / Slow
▶II	Play / Pause	STEP - FREEZE II	Pause / Step / Freeze
◀◀	<<	TUNE- ◀◀	<< / Tune-
▶▶	>>	TUNE+ ▶▶	>> / Tune+
●	Rec	REC MODE ●	Rec / Rec Mode
■	Stop	HOLD ■	Stop / Hold
⏮	I<<	PRESET- ⏮	I<< / Preset-
⏭	>>I	PRESET+ ⏭	>>I / Preset+
	Red	NETFLIX SEARCH	Red / Netflix / Search

Original		Replacement	
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random