Mandis shop

Saba TC352

Original		Rechange		Original	Rechange
ON/OFF	On/Off		Power		
–	Channel-	CH –	CH -		
+	Channel+	+ CH	CH +		
REW	<< Rew		Rewind		
REW	<<Shuttle/Search		First		
FF	FF >>		Fast Forward		
FF	Shuttle/Search		Last		
PLAY	Play		Play		
STOP	Stop		Stop		
REC	Rec		Rec		
PAUSE	Pause		Pause		

https://telecommandes-mandis.be/fr/1009816-83688-telecommande-de-remplacement-pour-Saba-TC352.html