| Original | | Rechange | |
|---|---|---|---|
| | Power | | Power |
| MY APPS | My Apps | APP MEDIA | Media |
| TV/RAD | TV/Radio | SEARCH TV/R | TV/R |
| 1 | 1 | 1 | 1 |
| 2 abc | 2 | 2 | 2 |
| 3 def | 3 | 3 | 3 |
| 4 ghi | 4 | 4 | 4 |
| 5 jkl | 5 | 5 | 5 |
| 6 mno | 6 | 6 | 6 |
| 7 pqrs | 7 | 7 | 7 |
| 8 tuv | 8 | 8 | 8 |
| 9 wxyz | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| LIST | List | DISC NAV LIST | List |
| Q.VIEW | Q.View | PICTURE FORMAT | Format |
| INPUT | Input | TIMER AV | AV |
| SUBTITLE Q.MENU | Q.Menu/Subtitle | AD SUBT | Subt |

| Original | | Rechange | |
|---|---|---|---|
| GUIDE | Guide | GUIDE | Guide |
| INFO | Info | DISPLAY INFO | Info |
| MUTE | Mute | MUTE | Mute |
| | Vol+ | + VOL | Vol + |
| | Vol- | VOL − | Vol - |
| P PAGE | Page+ | + CH | Ch + |
| P PAGE | Page- | CH − | Ch - |
| TEXT | Text | REPEAT TEXT | Text |
| T.OPT | T.Opt | SETTINGS OPT | Options |
| SMART | Smart | HOME SMART | Smart |
| FAV | FAV | FAV PRE-CH | Pre Ch |
| BACK | Back | RETURN BACK | Back |
| EXIT | Exit | CLEAR EXIT | Exit |
| OK | OK | OK | Ok |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |

| Original | | Rechange | | Original | Rechange |
|---|---|---|---|---|---|
| | Left | | Left | | |
| | Red | A | Red | | |
| | Green | B | Green | | |
| | Yellow | C | Yellow | | |
| | Blue | D | Blue | | |
| LIVE TV | Stop/Line TV | | Stop | | |
| REC/* | Rec/* | REC MODE | Rec | | |
| | Play | PLAY MODE | Play | | |
| | Pause | | Pause | | |
| | >> | | >> | | |
| | << | | << | | |
| APP/* | APP/* | SHIFT + APP MEDIA | Shift + Media | | |
| AD | AD | SHIFT + AD SUBT | Shift + Subt | | |
| SETTINGS | Settings | SHIFT + SETTINGS OPT | Shift + Options | | |
| | | | | | |
| | | | | | |
| | | | | | |