Original		Rechange	
POWER	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
PR.LIST	PR. List	LIST SMART	Smart / List
0	0	HDMI - SAT 0	0
RECALL	Recall	RETURN BACK	Back / Return
VOL +	Vol +	VOL +	Vol +
PIC.MODE	PIC. Mode	FORMAT PICTURE	Picture / Format
S.MODE	S. Mode	TITLE SOUND	Sound / Title

Original		Rechange	
CH +	CH+	CH PAGE +	CH+ / Page+
VOL −	Vol -	VOL −	Vol -
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
CH −	CH-	CH PAGE −	CH- / Page-
▲	Up	▲	Up
◀	Left	◀	Left
OK	OK	OK	OK
▶	Right	▶	Right
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
▼	Down	▼	Down
MENU	Menu	HOME MENU	Menu / Home
ASPECT	Aspect	SHIFT + FORMAT PICTURE	Shift + Picture / Format
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
REC	Rec	REC MODE	Rec / Rec Mode
REC LIST	Rec List	MEDIA DISPLAY	Display / Media
DVD-SETUP	Red/ DVD Setup	OPT-TOOLS SETUP	Setup / OPT /
DVD-SETUP	Red/ DVD Setup	NETFLIX SEARCH	Red / Netflix / Search

Original	Rechange
Green/Repeat	APP / REPEAT — Green / APP / Repeat
Yellow/Languag	YouTube / REPEAT A-B — Yellow / YouTube / Repeat
Yellow/Languag	SHIFT + LANG I/II / AUDIO — Shift + Audio / Lang I/II
Blue/DVD Menu	TOP MENU / D.MENU — D. Menu / Top
Blue/DVD Menu	Prime Video / RANDOM — Blue / Prime Video / Random
Title/PC Auto	PC / FAV MARKER — Fav / Marker / PC
Title/PC Auto	SHIFT + TITLE / SOUND — Shift + Sound / Title
Tv/Radio	PROGRAM / TV/RADIO — TV/Radio /
Zoom	SIZE / ZOOM — Zoom / Size
I-II/Audio	LANG I/II / AUDIO — Audio / Lang I/II
Subtitle	EQ / SUBTITLE — Subtitle / EQ
Prog/Index	-/-- / GUIDE EPG — Guide / EPG / -/--
Prog/Index	SHIFT + PROGRAM / TV/RADIO — Shift + TV/Radio / Program
A-B/Reveal	SHIFT + YouTube / REPEAT A-B — Shift + Yellow / YouTube /
Step/Freeze	SHIFT + STEP-FREEZE / II — Shift + Pause / Step /
Info/Display	ANGLE / INFO — Info / Angle
Text	GOTO / TEXT — Text / Goto

Original	Rechange
Open/Close	SURROUND / ⏏ — Eject / Surround
Play/Size	SLOW / ▶ — Play / Slow
Play/Size	SHIFT + SIZE / ZOOM — Shift + Zoom /
Pause/Subpage	STEP-FREEZE / II — Pause / Step / Freeze
Stop/Hold	HOLD / ■ — Stop / Hold
I<<	PRESET- / ⏮ — I<< / Preset-
>>I	PRESET+ / ⏭ — >>I / Preset+
<<	TUNE- / ◀◀ — << / Tune-
>>	TUNE+ / ▶▶ — >> / Tune+