Original		Rechange	
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
i	i	DISPLAY INFO	Info
MUTE	Mute	MUTE	Mute
TV/RADIO	Tv/Radio	SEARCH TV/R	TV/R
INPUT	Input	TIMER AV	AV
DIGITAL MENU	Digital Menu	SHIFT +	TOP MENU MENU Shift + Menu
MENU SETUP	Menu/Setup	TOP MENU MENU	Menu
EXIT/ CANCEL	Exit/Cancel	CLEAR EXIT	Exit

Original		Rechange	
DVD MENU	DVD Menu	E-MANUAL D.MENU	D. Menu
TOP MENU	Top Menu	DISC NAV LIST	List
GUIDE	Guide	GUIDE	Guide
CH	CH+	+ CH	Ch +
PAGE	CH-	CH −	Ch -
+ VOL	Vol +	+ VOL	Vol +
− VOL	Vol -	VOL −	Vol -
EJECT	Eject	ZOOM	Eject
TV/DVD	Tv/DVD	HOME SMART	Smart
ATV/DTV	ATV/DTV	APP MEDIA	Media
ENTER/ CH LIST	Enter/CH. List	OK	Ok
	Left		Left
	Right		Right
	Up		Up
	Down		Down
PLAY	Play	PLAY MODE	Play
STOP	Stop		Stop

Original		Rechange	
RETURN	Return	RETURN BACK	Back
REV	<<</ Rev/ [≡?]	<<	<<
SKIP	I <<</ [≡+]	K<<	I <<
SKIP	>>I / [≡♦]	>>I	>>I
FF	>>/ FF/ [≡o]	>>	>>
PAUSE	Pause	II	Pause
PAUSE	Green	B	Green
PLAY MODE	Yellow/play Mode	C	Yellow
SLOW	Blue/ I > Slow	D	Blue
SLOW	Red/ ◁ Slow	A	Red
	[≡]	REPEAT TEXT	Text
SLEEP	Sleep	PROG SLEEP	Sleep
SUBTITLE	Subtitle	AD SUBT	Subt
REPEAT A-B	Repeat A-B	SHIFT + PLAY MODE ▶	Shift + Play
AUDIO SELECT	Audio Select	SOUND DUAL	Dual
CH RTN ZOOM	Zoom/CH RTN	ECO 3D	3D
PIC SIZE	Pic Size	PICTURE FORMAT	Format

Original		Rechange	
ANGLE	Angle	REC MODE ●	Rec
MARKER	Marker	SETTINGS OPT	Options
JUMP	Jump	FAV PRE-CH	Pre Ch
⏻/I	Power	⏻	Power