Original		Rechange	
	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
TIMER	Timer	SHIFT + TIMER AV	Shift + AV
	Open/Close	ZOOM	Eject
D-IN	D-IN	SETTINGS OPT	Options
AUX	AUX	TIMER AV	AV
LDER NEXT	Folder Next	+ CH	Ch +
FOL PREV.	Folder Prev.	CH −	Ch -
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9

Original		Rechange	
0	0	0	0
≥10	+10	-/-- GUIDE	Guide
CLEAR PTY	PTY/Clear	CLEAR EXIT	Exit
DIMMER	Dimmer	RETURN BACK	Back
SHUFFLE	Shuffle	TOP MENU MENU	Menu
REPEAT	Repeat	REPEAT TEXT	Text
P.MODE	P.Mode	PICTURE FORMAT	Format
D-BASS	D-Bass	AD SUBT	Subt
TONE	Tone	C	Yellow
FLAT	Flat	SOUND DUAL	Dual
DISPLAY	Display	DISPLAY INFO	Info
MODE	Mode	ECO 3D	3D
TUNER/B.	Tuner/Band	SEARCH TV/R	TV/R
VOLUME	Vol+	+ VOL	Vol +
	Vol-	VOL −	Vol -
MUTE	Mute	MUTE	Mute
	Up		Up

Original		Rechange		Original	Rechange
	Down		Down		
	Right		Right		
	Left		Left		
ENTER	Enter	OK	Ok		
D.AUDIO	D.Audio	A	Red		
CD	Play/Pause CD	PLAY MODE	Play		
iPod	Play/Pause iPod		Pause		
USB	Play/Pause USB	B	Green		
AUTO/MONO	Stop/Auto/Mono		Stop		
P.CALL	I<< P.Call		I<<		
CALL	P.Call/>>I		>>I		
TUNING	<< Tuning		<<		
TUNING	Tuning >>		>>		