Original	Rechange
On/Standby	Power
Memory	Menu
Clear/Dimmer	Exit
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
+10	Guide
Vol +	Vol +
Vol -	Vol -
X-Bass	Media

Original	Rechange
Equalizer Mode	Smart
CD	Yellow
Tuner/Band	Blue
Tape	Green
Video/AUX	Red
Disc Select 1	Sleep
Disc Select 2	TV/R
Disc Select 3	Format
Disc Select 4	3D
Disc Select 5	D. Menu
Random CD	Dual
Pause CD	Pause
Stop CD	Stop
Play CD	Play
< Tape	<<
Tape >	>>
Stop Tape	Shift + Stop

Original	Rechange	Original	Rechange
Rec/Pause Tape	Rec		
Character	Options		
Up	Up		
Down	Down		
Right	Right		
Left	Left		
Enter	Ok		
Display	Info		
Navigation	List		
Clock/Timer	AV		
I <<</ <<</ Preset -	I <<		
>>I / >>/ Preset	>>I		