Mandis shop

# Sony RM-SC50

| Original | | Rechange | |
|---|---|---|---|
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer |
| I / ⏻ | Power | ⏻ | Power |
| DISPLAY | Display | MEDIA DISPLAY | Display / Media |
| SELECT | Clock Timer | TOP MENU D.MENU | D.Menu / Top |
| SET | Clock Timer Set | HOME MENU | Menu / Home |
| TUNER MEMORY | Tuner Memory | ◀ | Left |
| PLAY MODE/ TUNING MODE | Play Mode/Tuning Mode | ▶ | Right |
| REPEAT/ FM MODE | Repeat/FM | APP REPEAT | Green / APP / Repeat |
| REPEAT/ FM MODE | Repeat/FM | ▼ | Down |
| TAPE | Tape | TAPE 5 | 5 |
| CD | CD | CD - STB 3 | 3 |
| TUNER BAND | Band/Tuner | ▲ | Up |
| TUNER BAND | Band/Tuner | TUNER 6 | 6 |
| FUNCTION | Function | LIST SMART | Smart / List |
| – ⏮ | I<<\/- | PRESET- ⏮ | I<< / Preset- |
| + ⏭ | >>I/+ | PRESET+ ⏭ | >>I / Preset+ |
| ◀◀ | << | TUNE- ◀◀ | << / Tune- |

| Original | | Rechange | |
|---|---|---|---|
| ▶▶ | >> | TUNE+ ▶▶ | >> / Tune+ |
| ▶ | Play | SLOW ▶ | Play / Slow |
| ⏸ | Pause | STEP - FREEZE ⏸ | Pause / Step / Freeze |
| ■ | Stop | HOLD ■ | Stop / Hold |
| CLEAR | Clear | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| VOLUME + | Vol+ | + VOL | Vol+ |
| ENTER | Enter | OK | OK |
| EQ | EQ | EQ SUBTITLE | Subtitle / EQ |
| VOLUME – | Vol- | VOL – | Vol- |
| DISC SKIP | Disc Skip | SURROUND ⏏ | Eject / Surround |
| 🗀 – | Folder- | CH PAGE – | CH- / Page- |
| 🗀 + | Folder+ | + CH PAGE | CH+ / Page+ |

https://telecommandes-mandis.be/fr/Sony/1055954-6103-telecommande-de-remplacement-pour-Sony-RM-SC-50-A1108433B.html