Original		Rechange	
POWER	Power		Power
INPUT	Input	TIMER AV	AV
MULTIMEDIA	Multimedia	APP MEDIA	Media
	Stop		Stop
	Play	PLAY MODE	Play
	Pause		Pause
	Rec	REC MODE	Rec
	<<		<<
MARK	>>		>>
	I <<		I <<
LIVE TV	>>I		>>I
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
XSTUDIO	XStudioPro	HOME SMART	Smart
	Up		Up
	Down		Down
	Left		Left

Original		Rechange	
	Right		Right
OK	Ok	OK	Ok
PIP PR-	Red	A	Red
PIP PR+	Green	B	Green
SWAP	Yellow	C	Yellow
PIP INPUT	Blue	D	Blue
VOL	Vol +	+ VOL	Vol +
VOL	Vol -	VOL –	Vol -
MUTE	Mute	MUTE	Mute
TEXT	Text	REPEAT TEXT	Text
PR	PR+	+ CH	Ch +
PR	PR-	CH –	Ch -
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5

Original	Rechange
6	6
7	7
8	8
9	9
0	0
List	List
Q. View	Options
Size	Format
Position	Subt
Index	Info
Time	SHIFT + TIMER AV — Shift + AV
Sleep	Sleep
Reveal	D. Menu
Hold	TV/R
Fav	Pre Ch
PIP	3D
ARC	Guide

Original	Rechange
I/II	Dual

Original		Rechange	
POWER	Power		Power
INPUT	I nput	TIMER AV	AV
	St op		St op
	Pl ay	PLAY MODE	Pl ay
	Pause		Pause
	Rec	REC MODE	Rec
	<<		<<
MARK	>>		>>
PR	PR+	+ CH	Ch +
PR	PR-	CH −	Ch -
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7

Original		Rechange	
8	8	8	8
9	9	9	9
0	0	0	0