Original	Rechange	Original	Rechange
Input	AV / Input / RDS	Ok	OK
XStudioPro	TV/Radio /	Down	Down
Power	Power	Red	Red / Netflix / Search
Multimedia	Display / Media	Green	Green / APP / Repeat
Stop	Stop / Hold	Yellow	Yellow / YouTube / Repeat
Play	Play / Slow	Blue	Blue / Prime Video / Random
Pause	Pause / Step / Freeze	Vol +	Vol +
Rec	Rec / Rec Mode	PR+	CH+ / Page+
I <<	I << / Preset-	Vol -	Vol -
<<	<< / Tune-	Mute	Mute / Dimmer
>>	>> / Tune+	Text	Text / Goto
>>I	>>I / Preset+	PR-	CH- / Page-
Menu	Menu / Home	1	1
Exit	Exit / Cancel / Clear	2	2
Left	Left	3	3
Up	Up	4	4
Right	Right	5	5

Original		Rechange		Original		Rechange	
6	6	TUNER 6	6	ARC	ARC	OPT-TOOLS SETUP	Setup / OPT /
7	7	AUX - HDD 7	7				
8	8	USB 8	8				
9	9	BLUETOOTH 9	9				
LIST	List	LIST SMART	Smart / List				
0	0	HDMI - SAT 0	0				
Q.VIEW	Q. View	TOP MENU D.MENU	D. Menu / Top				
SIZE	Size	SIZE ZOOM	Zoom / Size				
POSITION	Position	EQ SUBTITLE	Subtitle / EQ				
TIME	Time	SHIFT + TIMER SLEEP	Shift + Sleep / Timer				
INDEX	Index	ANGLE INFO	Info / Angle				
HOLD	Hold	SHIFT + HOLD	Shift + Stop /				
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer				
REVEAL	Reveal	TITLE SOUND	Sound / Title				
FAV	Fav	PC FAV MARKER	Fav / Marker / PC				
I/II	I/II	LANG I/II AUDIO	Audio / Lang I/II				
PIP	PIP	FORMAT PICTURE	Picture / Format				

Original		Rechange	
POWER	Power		Power
	Stop	HOLD	Stop / Hold
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	I <<	PRESET-	I << / Preset-
	<<	TUNE-	<< / Tune-
MARK	>>	TUNE+	>> / Tune+
LIVE TV	>>I	PRESET+	>>I / Preset+
MENU	Menu	HOME MENU	Menu / Home
	Left		Left
	Up		Up
	Right		Right
OK	OK	OK	OK
	Down		Down
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3

Original		Rechange	
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0

Original		Rechange		Original		Rechange	
INPUT	Input	RDS AV INPUT	AV / Input / RDS	8	8	USB 8	8
POWER	Power		Power	9	9	BLUETOOTH 9	9
	Stop	HOLD	Stop / Hold	0	0	HDMI - SAT 0	0
	Play	SLOW	Play / Slow				
	Pause	STEP - FREEZE	Pause / Step / Freeze				
	Rec	REC MODE	Rec / Rec Mode				
	<<	TUNE-	<< / Tune-				
MARK	>>	TUNE+	>> / Tune+				
PR	PR+	+ CH PAGE	CH+ / Page+				
PR	PR-	CH PAGE −	CH- / Page-				
1	1	TV 1	1				
2	2	DVD 2	2				
3	3	CD - STB 3	3				
4	4	VIDEO 4	4				
5	5	TAPE 5	5				
6	6	TUNER 6	6				
7	7	AUX - HDD 7	7				

Original	Rechange	Original	Rechange
Power	Power		
Vol +	Vol +		
Vol -	Vol -		
Mute	Mute / Dimmer		