Original		Rechange	
STANDBY/ON	Standby/on		Power
OPEN/CLOSE	Open/close	SURROUND	Eject / Surround
CD	CD	SHIFT + CD - STB 3	Shift + 3
USB	USB	SHIFT + USB 8	Shift + 8
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6
AUDIO IN	Audio In	LANG I/II AUDIO	Audio / Lang I/II
BT AUDIO	BT Audio	SHIFT + BLUETOOTH 9	Shift + 9
CLOCK/TIMER	Clock/Timer	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
EQUALIZER	Equalizer	OPT-TOOLS SETUP	Setup / OPT /
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
P.BASS	P.Bass	TITLE SOUND	Sound / Title

Original		Rechange	
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
BASS/TREBLE	Bass/Treble	SHIFT + TITLE SOUND	Shift + Sound / Title
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
0	0	HDMI - SAT 0	0
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random
DISPLAY	Display	MEDIA DISPLAY	Display / Media
TUNE+	Up/Tune+		Up
FOLDER	Folder	GOTO TEXT	Text / Goto
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
MENU	Menu	HOME MENU	Menu / Home
TUNE–	Down/Tune-		Down
MEMORY/ PROGRAM	Memory/Progra m	PROGRAM TV/ RADIO	TV/Radio / Program

Original		Rechange		Original	Rechange
PRESET +	Preset+	PRESET+	>>I / Preset+		
MUTE	Mute	DIMMER MUTE	Mute / Dimmer		
VOLUME +	Vol+	+ VOL	Vol+		
–	Preset-	PRESET-	I<< / Preset-		
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer		
–	Vol-	VOL –	Vol-		
	<<|<<	TUNE-	<< / Tune-		
	Stop	HOLD	Stop / Hold		
	Play	SLOW	Play / Slow		
	Pause	STEP · FREEZE	Pause / Step / Freeze		
	>>/>>I	TUNE+	>> / Tune+		
ST/MONO	ST/Mono	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II		
RDS ASPM	RDS ASPM	SHIFT + LIST SMART	Shift + Smart / List		
PTY	RDS PTY	LIST SMART	Smart / List		
DISPLAY	RDS Display	SHIFT + MEDIA DISPLAY	Shift + Display / Media		