Original		Rechange		Original		Rechange	
	Power		Power		Option		Setup / OPT /
SD CARD	SD Card	SHIFT + MEDIA DISPLAY	Shift + Display / Media		Down		Down
INP TV	Input TV	RDS AV INPUT	AV / Input / RDS	BACK/ RETURN	Return/Back	RETURN BACK	Back / Return
PUT AV	Input AV	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS		Red	NETFLIX SEARCH	Red / Netflix / Search
MENU	Menu	HOME MENU	Menu / Home		Green	APP REPEAT	Green / APP / Repeat
ASPECT	[+]/Aspect	FORMAT PICTURE	Picture / Format		Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
INTERNET	Internet	LIST SMART	Smart / List		Blue	Prime Video RANDOM	Blue / Prime Video / Random
DIRECT TV REC	Direct Tv Rec	SHIFT + REC MODE	Shift + Rec / Rec Mode	TEXT	[≡]/Text	GOTO TEXT	Text / Goto
	i	ANGLE INFO	Info / Angle	STTL	[≡♦]/Sttl	EQ SUBTITLE	Subtitle / EQ
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear	INDEX	[≡i]/Index	PROGRAM TV/ RADIO	TV/Radio /
VIERA TOOLS	Viera Tools	MEDIA DISPLAY	Display / Media	HOLD	[≡+]/Hold	SHIFT + HOLD	Shift + Stop /
VIERA Link	Viera Link	TOP MENU D.MENU	D.Menu / Top	1	1	TV 1	1
	Up		Up	2abc	2	DVD 2	2
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--	3def	3	CD - STB 3	3
	Left		Left	4ghi	4	VIDEO 4	4
OK	OK	OK	OK	5jkl	5	TAPE 5	5
	Right		Right	6mno	6	TUNER 6	6

Original		Rechange	
7 pqrs	7	AUX - HDD 7	7
8 tuv	8	USB 8	8
9 wxyz	9	BLUETOOTH 9	9
Mute	Mute	DIMMER MUTE	Mute / Dimmer
0	0	HDMI - SAT 0	0
LAST VIEW	Last View	PC FAV MARKER	Fav / Marker / PC
+	Vol +	+ VOL	Vol +
∧	CH+	+ CH PAGE	CH+ / Page+
−	Vol -	VOL −	Vol -
∨	CH-	CH PAGE −	CH- / Page-
Power	Power Tv	SHIFT + Power	Shift + Power
REC	Rec Tv	REC MODE	Rec / Rec Mode
PROG ∨	Programme Down	SHIFT + CH PAGE −	Shift + CH- /
AMME ∧	Programme Up	SHIFT + CH PAGE +	Shift + CH+ /
⏮ ◀◀	<<I << Tv	TUNE- ◀◀	<< / Tune-
⏮ ◀◀	<<I << Tv	PRESET- ⏮	I << / Preset-
▶	Play Tv	SLOW ▶	Play / Slow

Original		Rechange	
▶▶I ▶▶	>>/ >>I Tv	TUNE+ ▶▶	>> / Tune+
▶▶I ▶▶	>>/ >>I Tv	PRESET+ ▶▶I	>>I / Preset+
■	Stop Tv	HOLD ■	Stop / Hold
II/▶	Pause/Step Tv	STEP - FREEZE II	Pause / Step / Freeze

Original	Rechange	Original	Rechange
Power DVD/VCR	Power		
Rec DVD/VCR	Rec / Rec Mode		
Programme Down DVD/VCR	CH- / Page-		
Programme Up DVD/VCR	CH+ / Page+		
<<| <<	<< / Tune-		
<<| <<	| << / Preset-		
Play DVD/VCR	Play / Slow		
>>| >>|	>> / Tune+		
>>| >>|	>>| / Preset+		
Stop DVD/VCR	Stop / Hold		
Pause/Step	Pause / Step / Freeze		