Original	Rechange	Original	Rechange
Play Mode	SHIFT + SLOW ▶ Shift + Play /	CLEAR Clear	EXIT / CANCEL Exit / Cancel / Clear
REPEAT Repeat	APP / REPEAT Green / APP / Repeat	CD SYN / NORMAL CD Synchro	SIZE / ZOOM Zoom / Size
DISPLAY Display	MEDIA / DISPLAY Display / Media	SYNCHRO / HIGH CD Synchro	FORMAT / PICTURE Picture / Format
SCROLL Scroll	ANGLE / INFO Info / Angle	▷ Play	SLOW ▶ Play / Slow
TIME Time	TIMER / SLEEP Sleep / Timer	❚❚ Pause	STEP-FREEZE ❚❚ Pause / Step / Freeze
YES Yes	OK OK	■ Stop	HOLD ■ Stop / Hold
'-/. 1 1	TV 1 1	AMS ⏮ I <<	PRESET- ⏮ I << / Preset-
ABC 2 2	DVD 2 2	AMS ⏭ >>I	PRESET+ ⏭ >>I / Preset+
DEF 3 3	CD-STB 3 3	ALBUM + CH+ / Page+	+ CH PAGE CH+ / Page+
GHI 4 4	VIDEO 4 4	< ◀◀ <<	TUNE- ◀◀ << / Tune-
JKL 5 5	TAPE 5 5	> ▶▶ >>	TUNE+ ▶▶ >> / Tune+
MNO 6 6	TUNER 6 6	DISC SKIP Disc Skip	PC / FAV MARKER Fav / Marker / PC
PQRS 7 7	AUX-HDD 7 7	ALBUM - CH- / Page-	CH PAGE -
TUV 8 8	USB 8 8		
WXYZ 9 9	BLUETOOTH 9 9		
>10 >10	-/-- GUIDE EPG Guide / EPG / -/--		
10/0 10/0	HDMI-SAT 0 0		

Original	Rechange	Original	Rechange
PLAY MODE Play Mode	SHIFT + SLOW ▶ Shift + Play /	WXYZ 9 9	BLUETOOTH 9 9
SBM SBM	LIST SMART Smart / List	>10 >10	-/-- GUIDE EPG Guide / EPG / -/--
REPEAT Repeat	APP REPEAT Green / APP / Repeat	10/0 10/0	HDMI - SAT 0 0
DISPLAY Display	MEDIA DISPLAY Display / Media	CLEAR Clear	CLEAR EXIT CANCEL Exit / Cancel / Clear
SCROLL Scroll	ANGLE INFO Info / Angle	INPUT Input	RDS AV INPUT AV / Input / RDS
TIME Time	TIMER SLEEP Sleep / Timer	CD SYN NORMAL CD Synchro	SIZE ZOOM Zoom / Size
MENU/NO Menu/No	HOME MENU Menu / Home	SYNCHRO HIGH CD Synchro	FORMAT PICTURE Picture / Format
NAME EDIT/ SELECT Name Edit/Select	OPT-TOOLS SETUP Setup / OPT /	FINALIZE Finalize	TOP MENU D.MENU D. Menu / Top
YES Yes	OK OK	ERASE Erase	RETURN BACK Back / Return
'-/, 1 1	TV 1 1	Rec	REC MODE Rec / Rec Mode
ABC 2 2	DVD 2 2	Play	SLOW ▶ Play / Slow
DEF 3 3	CD - STB 3 3	Pause	STEP - FREEZE Pause / Step / Freeze
GHI 4 4	VIDEO 4 4	Stop	HOLD Stop / Hold
JKL 5 5	TAPE 5 5	AMS I<<	PRESET- I<< / Preset-
MNO 6 6	TUNER 6 6	AMS >>I	PRESET+ >>I / Preset+
PQRS 7 7	AUX - HDD 7 7	< <<	TUNE- << / Tune-
TUV 8 8	USB 8 8	> >>	TUNE+ >> / Tune+

Original	Rechange	Original	Rechange
REC FADER Rec Fader	SHIFT + REC MODE Shift + Rec / Rec Mode		