Mandis shop

# Panasonic N2QAEC000023

| Original | | Rechange | |
|---|---|---|---|
| START/ STOP | Start/Stop | | Power |
| PHOTO SHOT | Photo Shot | SRC | Source |
| EXT DISPLAY | Ext/Display | 9 DISP | 9 / Disp |
| DATE/ TIME | Date/Time | GOTO | Eject / GOTO |
| ZOOM + T VOL | Zoom T/Vol+ | V+ | V+ |
| VOL – W | Zoom W/Vol- | V– | V- |
| SEARCH | << Search | SLOW | << |
| PLAY | Play | BAND | Play / Band |
| SEARCH | Search >> | STEP | >> |
| STILL ADV | <I Still ADV | | - |
| PAUSE | Pause | IIANG | IIAng |
| STILL ADV | Still ADV I> | | + |
| SKIP | I<< Skip | EQ | I< |
| STOP | Stop | RANDOM | Stop / Random |
| SKIP | Skip >>I | CLEAR | >I |
| | Delete/Spam | 3 EXIT | 3 / Exit |
| MENU | Menu | 2 MENU | 2 / Menu |

| Original | | Rechange | |
|---|---|---|---|
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| ENTER | Enter | OK | OK |

https://telecommandes-mandis.be/fr/Panasonic/1056912-9523-telecommande-de-remplacement-pour-Panasonic-N2QAEC000023.html