Mandis shop

Sony RM-SR110

Original		Rechange	
	Power		Power
FUNCTION	Play Function	C	Yellow
TAPE B	Play Tape B	B	Green
TUNER/BAND	Play Tuner / Band	SEARCH TV/R	TV/R
TAPE A	Play Tape A	A	Red
FLASH	Flash	DISPLAY INFO	Info
LOOP	Loop	RETURN BACK	Back
FILE SELECT	File Select	APP MEDIA	Media
MODE SELECT	Mode Select	HOME SMART	Smart
VOL	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
	>>		>>

Original		Rechange	
	<<		<<
	>>I / +		>>I
	I<< / -		I<<
	Stop		Stop
	Pause		Pause
CD	Play CD	PLAY MODE	Play
DISC SKIP	Disc Skip	CLEAR EXIT	Exit
SLEEP	Sleep	PROG SLEEP	Sleep

https://telecommandes-mandis.be/fr/Sony/1057363-91101-telecommande-de-remplacement-pour-Sony-RMSR110-141886211.html