Original		Rechange	
STANDBY/ON	Standby		Power
1 VCR/DVR	1/VCR/DVR	TV 1	1
2 CBL/SAT	2/CBL/SAT	DVD 2	2
3 GAME/TV	3/Game/TV	CD-STB 3	3
4 AUX	4/AUX	VIDEO 4	4
5 MULTI CH	5/Multi CH	TAPE 5	5
6 DVD	6/DVD	TUNER 6	6
7 TAPE	7/Tape	AUX-HDD 7	7
8 TUNER	8/Tuner	USB 8	8
9 CD	9/CD	BLUETOOTH 9	9
+10	+10/10/-/--/D.Tun	-/-- GUIDE EPG	Guide / EPG / -/--
0 DIMMER	0/11/Dimmer	HDMI-SAT 0	0
CLR	CLR/12/Sleep/Ent	PC FAV MARKER	Fav / Marker / PC
+ CH DISC ALBUM	CH Disc	+ CH PAGE	CH+ / Page+
CH DISC ALBUM –	CH Disc Album-	CH PAGE –	CH- / Page-
VOL	Vol+	+ VOL	Vol+
VOL	Vol-	VOL –	Vol-

Original		Rechange	
	Up		Up
PREVIOUS MENU MUTING	Previous Menu/Muting	HOME MENU	Menu / Home
	Left/Playlist/Cat		Left
ENTER	Enter	OK	OK
	Right/Playlist/Cat		Right
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
	Pause/<	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
STEREO	Stereo	TITLE SOUND	Sound / Title
SURROUND	Surround	SURROUND	Eject / Surround
	< Listening Mode	SHIFT +	Shift + Left
	Listening Mode >	SHIFT +	Shift + Right

Original	Rechange	Original	Rechange
AUDIO / TEST TONE — Test Tone/Audio	LANG I/II / AUDIO — Audio / Lang I/II		
SUBTITLE / CH SEL — CH Sel/Subtitle	EQ / SUBTITLE — Subtitle / EQ		
RANDOM / LEVEL- — Random Level-	Prime Video / RANDOM — Blue / Prime Video / Random		
REPEAT / LEVEL+ — Repeat Level+	APP / REPEAT — Green / APP / Repeat		
DISPLAY — Display	MEDIA / DISPLAY — Display / Media		
L NIGHT / DVD — L.Night/DVD	TIMER / SLEEP — Sleep / Timer		
CINE FLTR / HDD — Cine FLTR/HDD	PROGRAM / TV/RADIO — TV/Radio /		

Original		Rechange	
STANDBY/ON	Standby		Power
1 VCR/DVR	1/VCR/DVR	TV 1	1
2 CBL/SAT	2/CBL/SAT	DVD 2	2
3 GAME/TV	3/Game/TV	CD-STB 3	3
4 AUX	4/AUX	VIDEO 4	4
5 MULTI CH	5/Multi CH	TAPE 5	5
6 DVD	6/DVD	TUNER 6	6
7 TAPE	7/Tape	AUX-HDD 7	7
8 TUNER	8/Tuner	USB 8	8
9 CD	9/CD	BLUETOOTH 9	9
+10	+10/10/-/--/D.Tun	-/-- GUIDE EPG	Guide / EPG / -/--
0 DIMMER	0/11/Dimmer	HDMI-SAT 0	0
CLR	CLR/12/Sleep/Ent	PC FAV MARKER	Fav / Marker / PC
GUIDE TOP MENU	Guide/Top	TOP MENU D.MENU	D.Menu / Top
	Up		Up
PREVIOUS MENU MUTING	Previous Menu/Muting	HOME MENU	Menu / Home
	Left/Playlist/Cat		Left

Original		Rechange	
ENTER	Enter	OK	OK
	Right/Playlist/Cat		Right
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
	Pause/<	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
STEREO	Stereo	TITLE SOUND	Sound / Title
SURROUND	Surround	SURROUND	Eject / Surround
	< Listening Mode	CH PAGE	CH- / Page-
	Listening Mode >	CH PAGE	CH+ / Page+
AUDIO TEST TONE	Test Tone/Audio	LANG I/II AUDIO	Audio / Lang I/II

Original	Rechange	Original	Rechange
SUBTITLE / CH SEL — CH Sel/Subtitle	LIST / SMART — Smart / List		
RANDOM / LEVEL- — Level-/Random	Prime Video / RANDOM — Blue / Prime Video / Random		
REPEAT / LEVEL+ — Level+/Repeat	APP / REPEAT — Green / APP / Repeat		
DISPLAY — Display	MEDIA / DISPLAY — Display / Media		
PLAY MODE / VCR — Play Mode VCR	RDS / AV INPUT — AV / Input / RDS		
L NIGHT / DVD — L.Night/DVD	TIMER / SLEEP — Sleep / Timer		
CINE FLTR / HDD — Cine FLTR/HDD	PROGRAM / TV/RADIO — TV/Radio /		

Original		Rechange	
STANDBY/ON	Standby		Power
1 VCR/DVR	1/VCR/DVR	TV 1	1
2 CBL/SAT	2/CBL/SAT	DVD 2	2
3 GAME/TV	3/Game/TV	CD-STB 3	3
4 AUX	4/AUX	VIDEO 4	4
5 MULTI CH	5/Multi CH	TAPE 5	5
6 DVD	6/DVD	TUNER 6	6
7 TAPE	7/Tape	AUX-HDD 7	7
8 TUNER	8/Tuner	USB 8	8
9 CD	9/CD	BLUETOOTH 9	9
+10	+10/10/-/--/D.Tun	-/-- GUIDE EPG	Guide / EPG / -/--
0 DIMMER	0/11/Dimmer	HDMI-SAT 0	0
CLR	CLR/12/Sleep/Ent	PC FAV MARKER	Fav / Marker / PC
+ CH DISC ALBUM	Disc/Album	+ CH PAGE	CH+ / Page+
CH DISC ALBUM –	Disc/Album CH-	CH PAGE –	CH- / Page-
VOL	Vol+	+ VOL	Vol+
VOL	Vol-	VOL –	Vol-

Original		Rechange	
	Pause/<	STEP-FREEZE	Pause / Step / Freeze
	Play	SLOW	Play / Slow
	Stop	HOLD	Stop / Hold
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
STEREO	Stereo	LANG I/II AUDIO	Audio / Lang I/II
SURROUND	Surround	SURROUND	Eject / Surround
	< Listening Mode		Left
	Listening Mode >		Right
RANDOM LEVEL-	Level-/Random	Prime Video RANDOM	Blue / Prime Video / Random
REPEAT LEVEL+	Level+/Repeat	APP REPEAT	Green / APP / Repeat
DISPLAY	Display	MEDIA DISPLAY	Display / Media

Original		Rechange	
STANDBY/ON	Standby		Power
1 VCR/DVR	1/VCR/DVR	TV 1	1
2 CBL/SAT	2/CBL/SAT	DVD 2	2
3 GAME/TV	3/Game/TV	CD-STB 3	3
4 AUX	4/AUX	VIDEO 4	4
5 MULTI CH	5/Multi CH	TAPE 5	5
6 DVD	6/DVD	TUNER 6	6
7 TAPE	7/Tape	AUX-HDD 7	7
8 TUNER	8/Tuner	USB 8	8
9 CD	9/CD	BLUETOOTH 9	9
+10	+10/10/-/--/D.Tun	-/-- GUIDE EPG	Guide / EPG / -/--
0 DIMMER	0/11/Dimmer	HDMI-SAT 0	0
CH DISC ALBUM +	Disc/Album	CH PAGE +	CH+ / Page+
CH DISC ALBUM −	Disc/Album CH-	CH PAGE −	CH- / Page-
⏸	Pause/<	STEP-FREEZE ⏸	Pause / Step / Freeze
▶	Play	SLOW ▶	Play / Slow
■	Stop	HOLD ■	Stop / Hold

Original		Rechange	
◀◀	<<	TUNE- ◀◀	<< / Tune-
STEREO	Stereo	LANG I/II AUDIO	Audio / Lang I/II
SURROUND	Surround	SURROUND ⏏	Eject / Surround
◄	< Listening Mode	◄	Left
►	Listening Mode >	►	Right
PLAY MODE VCR	Play Mode/VCR	OK	OK
L NIGHT DVD	L.Night/DVD	TIMER SLEEP	Sleep / Timer